



CT7-2E INCREMENTAL CHANGE
MM 72-00-00, FAULT ISOLATION 001
FADEC FAULT ISOLATION (CT7-2E1)

Release Notification Date: 03/04/2021

DISCLAIMER

The Incremental Changes published by GE Aviation are considered Instructions for Continued Airworthiness. These Incremental Changes, along with the current Manual revision and published Temporary Revisions, constitute the latest Instructions for Continued Airworthiness.

GE Designated: -CONFIDENTIAL-

The information contained in this document is GE proprietary information and is disclosed in confidence. It is the property of GE and shall not be used, disclosed to others or reproduced without the express written consent of GE, including, but without limitation, it is not to be used in the creation, manufacture, development, or derivation of any repairs, modifications, spare parts, designs, or configuration changes or to obtain FAA or any other government or regulatory approval to do so. If consent is given for reproduction in whole or in part, this notice and the notice set forth on each page of this document shall appear in any such reproduction in whole or part.

This technical data is considered subject to the Export Administration Regulations (EAR) pursuant to 15 CFR Parts 730-774. Transfer of this data by any means to a Non-U.S. Person, whether in the United States or abroad, without the proper U.S. Government authorization (e.g., License, exemption, NLR, etc.), is strictly prohibited.

Copyright (2021) General Electric Company, U.S.A.

HIGHLIGHTS

<u>HIGHLIGHT REFERENCE</u>	<u>DESCRIPTION OF CHANGE</u>
tk72-00-00-810-809	Technical Change: Added Labels 003-15 and 004-15 to the List of FADEC Messages in Table 101 for CT7-2E1 Modified to SB 74-0004. Also added Labels 003-25 and 003-26 to List of Status Word Messages in Table 102 for CT7-2E1 Modified to SB 74-0004.

*** * * FOR CT7-2E1**

TASK 72-00-00-810-809

1. General Information.

- A. This section gives instructions to isolate fault conditions that result in the FADEC sending a fault message.
- B. Fault isolation procedures in this maintenance manual cover the latest FADEC software version.

NOTE: Two basic things are assumed in these procedures:

- * You must follow the current operating procedures.
- * A single failure or malfunction causes the fault isolation.

- C. Get as much information as possible from the flight crew that reports the problem. In many cases, this information will describe the fault completely. If possible, a ground test run should confirm the fault, if there is no danger to cause damage to the engine.
- D. Troubleshoot the fault:
 - (1) Fault Message Troubleshooting.
Go to when a fault message is sent by a FADEC.
 - (2) Many faults, particularly if intermittent and not corrected by the procedures in paragraph G, are best isolated by swapping suspect parts with known good parts to another engine, one at a time. When fault follows suspect part onto known good engine, isolation is assured.
- E. Use the following procedural guidelines when doing fault isolation:
 - (1) If possible, confirm the reported fault with a ground test run.
 - (2) Troubleshoot according to the symptoms.
 - (3) Complete the checks required (TEST).

(4) Confirm fault has been fixed with a ground test run.

F. Any fluctuation of engine related parameters, such as Ng speed, Np speed, torque, or TGT, may be due to dirty or inadequately secured electrical connectors. Contamination, moisture or looseness is particularly suspect when fault is intermittent. Such engine and airframe electrical connectors should be disconnected, inspected (74-00-00, INSPECTION), and cleaned (74-00-00, CLEANING) prior to next engine test and prior to any line replaceable unit (LRU) component removal.

2. How To Use Instructions.

NOTE: Record all fault messages before you perform maintenance on the engine, or before the engine is removed from the aircraft. Note the engine and FADEC message.

A. These procedures are used to isolate fault conditions that result in the FADEC sending a fault message.

B. Organization of the FADEC fault isolation tables

- (1) Each table checks for specific fault isolation messages.
- (2) Fault Descriptions. The FADEC message (Label-Bit) is listed with a description of the fault.
- (3) Instructions. Specific symptoms are listed and a question is asked that can be answered by either a yes or no.
- (4) Possible Faulty Components. For each fault message, the possible faulty components are listed.
- (5) Electrical Check. If an electrical check is required, measure the resistance of the applicable connectors and pins to be checked. If the resistance falls within the listed value, the answer to the component fault found is no.
- (6) Component Fault Found. Provides the direction to next symptom to be checked depending on whether the question was answered yes or no or corrects the problem.

C. Engine Electrical Troubleshooting Procedures:

The following is the guideline to troubleshoot an anomaly in the engine electrical system by fault message sent by the FADEC.

- (1) To prevent electrical shock, unless specified, be sure electrical power is off before working on the helicopter.
- (2) Use a hand held multimeter for all electrical component checks.
- (3) Use of a megger tester of less than 500 VDC to check insulation resistance is only permitted on certain electrical components: harnesses, sensors, PMA, FMU and switches. DO NOT megger test the EECU, this will damage the control.
- (4) Disconnect, inspect, clean and reconnect all electrical connectors during troubleshooting, ensure all connectors are secure and no bent pins. Connector cleaning agents must be per the following recommended specification or equivalent:

Specification No./Part No.	Nomenclature
M39029/4-110	Pin, Contact
M39029/4-111	Pin, Contact
- (5) When you make continuity checks, make sure component circuit is isolated.
- (6) At completion of checkout procedure, inspect all replaceable assembly and connectors removed and replaced during checkout procedure. All replaceable assembly and connectors shall be secure and free of foreign object damage (FOD).
- (7) A sensor's resistance can be influenced by extreme temperature ranges. For extreme heat and cold conditions, resistance values may vary up to 20%.

TABLE 101. LIST OF FADEC MESSAGES

LABEL	DESCRIPTION	TABLE
001-14	OTAT Fault CH A	Table 109
001-15	SIF Fault CH A	Table 158
001-16	Engine Out Signal Fault CH A Fault	Table 160
001-17	Overspeed System Test #3 CH A Fault	Table 187
001-18	Overspeed System Test #2 CH A Fault	Table 189
001-19	Overspeed System Test #1 CH A Fault	Table 187
001-20	VG System CH A Fault	Table 144
001-21	Wf System CH A Fault	Table 156
001-22	Anti-Ice System CH A Fault	Table 138
001-23	Anti-Ice Output CH A Fault	Table 136
001-24	Vapor Vent Output CH A Fault	Table 131
001-25	Wf Output CH A Fault	Table 154
001-26	VG Output CH A Fault	Table 139
001-27	Ignition Output CH A Fault	Table 132
001-28	Start Output CH A Fault	Table 162
001-29	Ignition, Starter, or Engine Out Relay Fault CH A	Table 178
002-14	OTAT Fault CH B	Table 109
002-15	SIF Fault CH B	Table 159

002-16	Engine Out Signal Fault CH B Fault	Table 161
002-17	Overspeed System Test #3 CH B Fault	Table 188
002-18	Overspeed System Test #2 CH B Fault	Table 189
002-19	Overspeed System Test #1 CH B Fault	Table 188
002-20	VG System CH B Fault	Table 144
002-21	Wf System CH B Fault	Table 156
002-22	Anti-Ice System CH B Fault	Table 138
002-23	Anti-Ice Output CH B Fault	Table 137
002-24	Altitude Fault CH B	Table 109
002-25	Wf Output CH B Fault	Table 155
002-26	VG Output CH B Fault	Table 140
002-27	Ignition Output CH B Fault	Table 133
002-28	Start Output CH B Fault	Table 163
002-29	Ignition, Starter, or Engine Out Relay Fault CH B	Table 179
003-14	Overspeed System Test Not Complete CH A Fault	Table 190

*** * * FOR CT7-2E1 MODIFIED TO SB 74-0004**

003-15	Cross-Channel Not Operational	Table 103
--------	-------------------------------	-----------

*** * * FOR CT7-2E1**

003-18	EECU Isolation Flag CH A	Table 104
003-20	EECU CH A Fault #2	Table 103
003-21	EECU CH A Fault #1	Table 103
003-22	Cross Engine Bus Tx CH A Fault	Table 164
003-23	ARINC TX1 CH A Fault	Table 164
003-24	ARINC RX2 CH A Fault	Table 165
003-25	ARINC RX1 CH A Fault	Table 165
003-26	EECU CH A Fault #8	Table 103
003-27	EECU CH A Fault #7	Table 103
003-28	Alternator Power CH A Fault	Table 128
003-29	28 VDC CH A Fault	Table 166
004-14	Overspeed System Test Not Complete CH B Fault	Table 190

*** * * FOR CT7-2E1 MODIFIED TO SB 74-0004**

004-15	Cross-Channel Not Operational	Table 103
--------	-------------------------------	-----------

*** * * FOR CT7-2E1**

004-18	EECU Isolation Flag CH B	Table 104
004-20	EECU CH B Fault #2	Table 103
004-21	EECU CH B Fault #1	Table 103
004-22	Cross Engine Bus Tx CH B Fault	Table 164
004-23	ARINC TX1 CH B Fault	Table 164
004-24	ARINC RX2 CH B Fault	Table 165
004-25	ARINC RX1 CH B Fault	Table 165
004-26	EECU CH B Fault #8	Table 103
004-27	EECU CH B Fault #7	Table 103
004-28	Alternator Power CH B Fault	Table 129
004-29	28 VDC CH B Fault	Table 167
005-14	PS3 Fault CH A	Table 115
005-15	P0 Fault	Table 113
005-16	Test Cell PAL Fault A	Table 181
005-17	Collective Fault A	Table 191
005-18	Wf LVDT Fault CH A	Table 151
005-19	VG LVDT Fault A	Table 141

005-20	Oil Temperature Fault	Table 126
005-21	Fuel Temp Fault CH A	Table 148
005-22	ITT Fault CH A	Table 118
005-23	T1 Fault CH A	Table 110
005-24	EECU CH A Fault #5	Table 103
005-25	EECU CH A Fault #4	Table 103
* * * FOR CT7-2E1 NOT MODIFIED TO SB 72-0013		
005-26	Torque Fault CH A	Table 121
* * * FOR CT7-2E1 MODIFIED TO SB 72-0013		
005-26	Torque Fault CH A	Table 194
* * * FOR CT7-2E1 NOT MODIFIED TO SB 72-0013		
005-27	Np Fault CH A	Table 121
* * * FOR CT7-2E1 MODIFIED TO SB 72-0013		
005-27	Np Fault CH A	Table 121A
* * * FOR CT7-2E1		
005-28	Ng FMU Fault A	Table 145
005-29	Ng Alternator Fault A	Table 128
006-14	PS3 Fault CH B	Table 116
006-15	Oil Pressure Fault	Table 127
006-16	Test Cell PAL Fault B	Table 182
006-17	Collective Fault B	Table 191
006-18	Wf LVDT Fault CH B	Table 152
006-19	VG LVDT Fault B	Table 142
006-20	Chip Detector Fault	Table 135
006-21	Fuel Temp Fault CH B	Table 149
006-22	ITT Fault CH B	Table 119
006-23	T1 Fault CH B	Table 111
006-24	EECU CH B Fault #5	Table 103
006-25	EECU CH B Fault #4	Table 103
* * * FOR CT7-2E1 NOT MODIFIED TO SB 72-0013		
006-26	Torque Fault CH B	Table 122
* * * FOR CT7-2E1 MODIFIED TO SB 72-0013		
006-26	Torque Fault CH B	Table 195
* * * FOR CT7-2E1 NOT MODIFIED TO SB 72-0013		
006-27	Np Fault CH B	Table 122
* * * FOR CT7-2E1 MODIFIED TO SB 72-0013		
006-27	Np Fault CH B	Table 122A
* * * FOR CT7-2E1		
006-28	Ng FMU Fault B	Table 146
006-29	Ng Alternator Fault B	Table 129
007-14	Cross Engine Bus B CH B Fault	Table 168
007-15	NR Fault CH B	Table 191

007-16	Oil Filter Bypass Fault	Table 124
007-17	Altitude Fault CH A	Table 109
007-18	Engine ID Fault CH B	Table 107
007-20	Wf On/Off Discrete Fault CH B	Table 170
007-21	Cross Engine Bus A CH B Fault	Table 168
007-22	Cross Engine Bus B CH A Fault	Table 168
007-23	NR Fault CH A	Table 191
007-24	Fuel Filter Bypass Fault	Table 134
007-25	Low Oil Pressure Fault	Table 125
007-26	Engine ID Fault CH A	Table 106
007-28	Wf On/Off Discrete Fault CH A	Table 169
007-29	Cross Engine Bus A CH A Fault	Table 168
008-14	AI Position FB Disagreement	Table 171
008-16	PS3 Disagree Fault	Table 117
008-17	P0 Disagree Fault	Table 114
008-18	Test Cell PAL Disagree Fault	Table 180
008-19	Collective Disagree Fault	Table 172
008-20	Wf LVDT Disagree Fault	Table 153
008-21	VG LVDT Disagree Fault	Table 143
008-22	Fuel Temp Disagree Fault	Table 150
008-23	ITT Disagree Fault	Table 120
008-24	T1 Disagree Fault	Table 112
008-25	EECU Fault #9	Table 103
008-26	Torque Disagree Fault	Table 123
008-27	Np Disagree Fault	Table 123
008-28	NG FMU Disagree Fault	Table 147
008-29	Ng Alternator Disagree Fault	Table 130
009-14	Engine ID Disagreement Between Engines	Table 108
009-16	EECU Software Version Miscompare Fault	Table 105
009-18	Crank Signal Disagree Fault	Table 183
009-19	WOW Fault	Table 109
009-20	Local Engine Channel A AEO Limit Selection Fault	Table 173
009-21	Local Engine Channel B AEO Limit Selection Fault	Table 174
009-22	SIF Disagreement	Table 175
009-23	AI Request Disagreement	Table 176
009-24	Training Input Disagreement	Table 177
009-25	Aircraft Data Fault	Table 109
009-26	Load Share Selection Switch Local Engine Disagree Fault	Table 186
009-27	OEI Limits Select Switch Fault	Table 157
009-28	Load Share Selection Switch Disagree Between Engines Fault	Table 185
009-29	Nr Signal Disagree Fault	Table 184

TABLE 102. LIST OF STATUS WORD MESSAGES

Label	Description	Table
001-25	EECU Exceeds Temperature Limit	Table 192
* * * FOR CT7-2E1 MODIFIED TO SB 74-0004		
003-25	Power Check Step Change Indication	Refer to SPECIAL PROCEDURES, Paragraph 13
003-26	Power Check No Margin Indication	Refer to FAULT ISOLATION 002, Figure 128
* * * FOR CT7-2E1		
001-29	Overspeed Test Not Completed	Table 193

TABLE 103. 003-21 - EECU CH A Fault #1 003-20 - EECU CH A Fault #2 005-25 - EECU CH A Fault #4 005-24 - EECU CH A Fault #5 003-27 - EECU CH A Fault #7 003-26 - EECU CH A Fault #8 004-21 - EECU CH B Fault #1 004-20 - EECU CH B Fault #2 006-25 - EECU CH B Fault #4 006-24 - EECU CH B Fault #5 004-27 - EECU CH B Fault #7 004-26 - EECU CH B Fault #8 008-25 - EECU Fault #9 003-15 - Cross-Channel Not Operational 004-15 - Cross-Channel Not Operational

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Restart the EECU. Is the fault corrected?	EECU				(c)	(b)
(b) Replace the EECU.						
(c) Continue to Operate.						

TABLE 104. 003-18 - EECU ISOLATION FLAG CH A 004-18 - EECU ISOLATION FLAG CH B

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Will not appear as a single fault. Clear all other faults to complete troubleshooting.						

TABLE 105. 009-16 - EECU SOFTWARE VERSION MISCOMPARE FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check software version installed on all 4 channels to determine which channel does not have the proper software version installed.						
(b) Reload the software where needed.						
(c) Continue to Operate.						

TABLE 106. 007-26 - ENGINE ID FAULT CH A

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check aircraft harnesses in CH A for proper wiring. Is it wired correctly?	Aircraft Harness	P1	33 to 34	Engine 1 open circuit. Engine 2 closed circuit.	(c)	(b)
(b) Replace faulty aircraft harness.						
(c) Replace						

the EECU.

TABLE 107. 007-18 - ENGINE ID FAULT CHANNEL B

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check aircraft harnesses in CH B for proper wiring. Is it wired correctly?	Aircraft Harness	P2	6 to 7	Engine 1 open circuit. Engine 2 closed circuit.	(c)	(b)
(b) Replace faulty aircraft harness.						
(c) Replace the EECU.						

TABLE 108. 009-14 - ENGINE ID DISAGREEMENT BETWEEN ENGINES

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check aircraft harnesses in CH A and CH B on both engines for proper wiring. Is it wired correctly?	Aircraft Harness	P1 P2	33 to 34 6 to 7	Engine 1 open circuit. Engine 2 closed circuit.	(c)	(b)
(b) Replace faulty aircraft harness.						
(c) Replace the EECU.						

TABLE 109. 009-25 - AIRCRAFT DATE FAULT 007-17 - ALTITUDE FAULT CH A 002-24 - ALTITUDE FAULT CH B 002-14 - OTAT FAULT CH B 001-14 - OTAT FAULT CH A 009-19 - WOW FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Troubleshoot according to the applicable Aircraft Maintenance Manual.						
(b) Continue to Operate.						
NOTE: WOW fault indicates inconsistent WOW inputs from aircraft or bad BITPACK A transmission or off-ground indicated with rotor speed <65%. ADF fault indicates faulty transmission of bitpack B, airspeed, or horsepower extraction signal. (For v3.0 software, this bit is always set and no fault is implied).						

TABLE 110. 005-23 - T2 FAULT CH A

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plugs at the EECU and FMU for tightness.	Blue Cable	P1 P19			(b)	(c)

Any loose connectors found?						
(b) Tighten loose connectors. Is fault cleared?					(h)	(c)
(c) Disconnect blue cable connector P1 at EECU. Measure T2 sensing circuit resistance through blue cable. Is the resistance correct?	EECU Blue Cable FMU	P1	40 to 39	50-200 ohms	(f)	(d)
(d) Disconnect FMU at P19 and measure the resistance. Is the resistance correct?		P19	5 to 6	50-200 ohms	(e)	(g)
(e) Replace the blue cable.						
(f) Replace the EECU.						
(g) Replace the FMU.						
(h) Continue to Operate.						

TABLE 111. 006-23 - T2 FAULT CH B

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plugs at the EECU and FMU for tightness. Any loose connectors found?	Green Cable	P2 P18			(b)	(c)
(b) Tighten loose connectors. Is fault cleared?					(h)	(c)
(c) Disconnect green cable connector P2 at EECU. Measure T2 sensing circuit resistance through green cable. Is the resistance correct?	EECU Green Cable FMU	P2	70 to 55	50-200 ohms	(f)	(d)
(d) Disconnect FMU at P18 and measure the resistance. Is the resistance correct?		P18	5 to 6	50-200 ohms	(e)	(g)
(e) Replace the green cable.						

- (f) Replace the ECU.
- (g) Replace the FMU.
- (h) Continue to Operate.

TABLE 112. 008-24 - T2 DISAGREE FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green and blue cables connector plugs at the ECU and FMU for tightness. Any loose connectors found?	Green Cable Blue Cable				(b)	(c)
(b) Tighten loose connectors. Is fault cleared?					(e)	(c)
(c) Swap FMU with known functioning FMU. Does the fault clear?	FMU				(e)	(d)
(d) Replace the ECU.						
(e) Continue to Operate.						

TABLE 113. 005-15 - P0 FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check the blue cable connector plug at ECU and P0 sensor for tightness. Any loose connector found?	Blue Cable	P1 J31			(b)	(c)
(b) Tighten loose connector plug. Fault cleared?					(h)	(c)
(c) Disconnect blue cable connector at P1. Measure resistance through blue cable for the following. Is the resistance correct?	Blue Cable P0 Sensor				(g)	(d)
- P0 sensor excitation		P1	74 to 63	1700-2000 ohms		
- P0 sensor output signal		P1	59 to 58	2200-2500 ohms		
(d) Disconnect P0 Sensor P31 connector plug at the P0					(e)	(f)

sensor.
 Measure
 resistance of
 the following:
 Is the
 resistance
 correct?

- P0 sensor J31 1 to 2 1700-2000 ohms
 excitation

- P0 sensor J31 3 to 4 2200-2500 ohms
 output signal

(e) Replace Blue Cable
 faulty cable.

(f) Replace P0 P0 Sensor
 sensor.

(g) Replace EECU
 EECU.

(h) Continue
 to operate.

TABLE 114. 008-17 - P0 DISAGREE FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check the blue cable connector plug at EECU and P0 sensor for tightness. Any loose connector found?	Blue Cable	P1 J31			(b)	(c)
(b) Tighten loose connector plug. Fault cleared?					(j)	(c)
(c) Swap suspect P0 sensor on engine 1 with known functioning sensor. Does the fault clear?	P0 Sensor				(h)	(d)
(d) Swap suspect P0 sensor on engine 2 with known functioning sensor. Does the fault clear?	P0 Sensor				(h)	(e)
(e) Swap suspect EECU on engine 1 with known functioning EECU. Does the fault clear?	EECU				(i)	(f)
(f) Swap suspect EECU on engine 2 with known functioning EECU. Does the fault clear?	EECU				(i)	
(g) Replace the blue						

- cable.
- (h) Replace P0 sensor.
- (i) Replace EECU.
- (j) Continue to Operate.

TABLE 115. 005-14 - PS3 FAULT CH A

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plugs at the EECU and P3 sensor for tightness, and check the two P3 tubes for damage or leakage. Any loose connectors or damage found?	Blue Cable P3 Tubes				(b)	(c)
(b) Tighten loose connector plugs or replace P3 tubes. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure the resistance through the blue cable for the following. Is the resistance correct?	EECU P3 Sensor Blue Cable				(f)	(d)
- P3 sensor A excitation		P1	79 to 78	1700-2000 ohms		
- P3 sensor A output signal		P1	73 to 72	2200-2500 ohms		
(d) Disconnect the P3 sensor at P25 and measure the resistance for the following. Is the resistance correct?	P3 Sensor				(e)	(g)
- P3 sensor A excitation		J25	1 to 2	1700-2000 ohms		
- P3 sensor A output signal		J25	3 to 4	2200-2500 ohms		
(e) Replace blue cable.						
(f) Replace EECU.						
(g) Replace P3 sensor.						
(h) Continue to Operate.						

TABLE 116. 006-14 - PS3 FAULT CH B

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plugs at the EECU and P3 sensor for tightness, and check the two P3 tubes for damage or leakage. Any loose connectors or damage found?	Green Cable P3 Tubes				(b)	(c)
(b) Tighten loose connector plugs or replace P3 tubes. Fault cleared?					(h)	(c)
(c) Disconnect P2 green cable connector at EECU. Measure the resistance through the green cable for the following. Is the resistance correct?	EECU P3 Sensor Green Cable				(f)	(d)
- P3 sensor A excitation		P2	72 to 73	1700-2000 ohms		
- P3 sensor A output signal		P2	71 to 78	2200-2500 ohms		
(d) Disconnect the P3 sensor at P26 and measure the resistance for the following. Is the resistance correct?	P3 Sensor				(e)	(g)
- P3 sensor A excitation		J26	1 to 2	1700-2000 ohms		
- P3 sensor A output signal		J26	3 to 4	2200-2500 ohms		
(e) Replace green cable.						
(f) Replace EECU.						
(g) Replace P3 sensor.						
(h) Continue to Operate.						

TABLE 117. 008-16 - PS3 DISAGREE FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green and blue cables connector plugs at the EECU and FMU	Green Cable Blue Cable EECU				(b)	(c)

for tightness.
 Any loose
 connectors
 found?

(b) Tighten loose connectors. Is fault cleared? (f) (c1)

(c1) Swap CH A P3 Sensor P3 sensor with known functioning P3 sensor. Does the fault clear? (d) (c2)

(c2) Swap CH B P3 Sensor P3 sensor with known functioning P3 sensor. Does the fault clear? (d) (e)

(d) Replace the faulty P3 sensor

(e) Replace the EECU.

(f) Continue to Operate.

TABLE 118. 005-22 - ITT FAULT CH A

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable and ITT connectors for tightness. Any loose connectors found?	Blue Cable ITT Harness	P1 P15			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure the resistance. Is the resistance correct?	EECU ITT Harness Blue Cable	P1	14 to 13	0.2-1.0 ohms	(f)	(d)
(d) Disconnect P15 connector at ITT harness. Measure ITT harness resistance.	ITT Harness	J15	A to B	0.2-1.0 ohms	(e)	(g)
(e) Replace blue cable.						
(f) Replace EECU.						
(g) Replace ITT harness.						
(h) Continue to Operate.						

NOTE: Resistances are given for room temperature and may vary significantly if ITT harness is hot or cold.

TABLE 119. 006-22 - ITT FAULT CH B

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable and ITT connectors for tightness. Any loose connectors found?	Blue Cable ITT Harness	P1 P15			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure the resistance. Is the resistance correct?	EECU ITT Harness Blue Cable	P1	11 to 10	0.2-1.0 ohms	(f)	(d)
(d) Disconnect P15 connector at ITT harness. Measure ITT harness resistance.	ITT Harness	J15	C to D	0.2-1.0 ohms	(e)	(g)
(e) Replace blue cable.						
(f) Replace EECU.						
(g) Replace ITT harness.						
(h) Continue to Operate.						

NOTE: Resistances are given for room temperature and may vary significantly if ITT harness is hot or cold.

TABLE 120. 008-23 - ITT DISAGREE FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable and ITT connectors for tightness. Any loose connectors found?	Blue Cable ITT Harness	P1 P15			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure the resistance. Is the resistance correct?	EECU ITT Harness Blue Cable	P1	14 to 13 11 to 10	0.2-1.0 ohms 0.2-1.0 ohms	(f)	(d)
(d) Disconnect P15 connector at ITT harness.	ITT Harness	J15	A to B C to D	0.2-1.0 ohms 0.2-1.0 ohms	(e)	(g)

Measure ITT harness resistance.

(e) Replace blue cable. Does the fault clear?

(h)

(g)

(f) Replace faulty EECU.

(g) Replace ITT harness.

(h) Continue to Operate.

NOTE: Resistances are given for room temperature and may vary significantly if ITT harness is hot or cold.

* * * FOR CT7-2E1 NOT MODIFIED TO SB 72-0013

TABLE 121. 005-27 - NP FAULT CH A 005-26 - TORQUE FAULT CH A

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
NOTE: To check if fault is cleared, it is necessary to motor the engine.						
(a) Check blue cable and Np sensor coil for tightness. Any loose connectors found?	Blue Cable				(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure Np sensor coil resistance through blue cable. Is the resistance correct?	EECU Np Sensor Blue Cable	P1	16 to 17	13.5-21.5 ohms	(f)	(d)
(d) Disconnect Np sensor connector plug P17. Measure resistance of Np sensor at connector pins. Is the resistance correct?	Blue Cable Np Sensor	J17	A to C B to D	13.5-21.5 ohms	(e)	(g)
(e) Replace blue cable.						
(f) Replace faulty EECU.						
(g) Replace Np sensor.						
(h) Continue to Operate.						

* * * FOR CT7-2E1 MODIFIED TO SB 72-0013

TABLE 121A.. 005-27 - NP FAULT CH A

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
NOTE: To check if fault is cleared, it is necessary to motor the engine.						

(a) Check blue Blue Cable cable and Np sensor coil for tightness. Any loose connectors found?					(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect EECU P1 blue cable connector at EECU. Measure Np sensor coil resistance through blue cable. Is the resistance correct?	P1		16 to 17	13.5-21.5 ohms	(f)	(d)
(d) Disconnect Blue Cable Np sensor connector plug P17. Measure resistance of Np sensor at connector pins. Is the resistance correct?	J17		A to C B to D	13.5-21.5 ohms	(e)	(g)
(e) Replace blue cable.						
(f) Replace faulty EECU.						
(g) Replace Np sensor.						
(h) Continue to Operate.						

* * * FOR CT7-2E1 NOT MODIFIED TO SB 72-0013

TABLE 122. 006-27 - NP FAULT CH B 006-26 - TORQUE FAULT CH B

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
NOTE: To check if fault is cleared, it is necessary to motor the engine.						
(a) Check green cable and Np sensor coil for tightness. Any loose connectors found?	Green Cable				(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect EECU P2 green cable connector at EECU. Measure Np sensor coil resistance through green cable. Is the resistance correct?	P2		50 to 27	13.5-21.5 ohms	(f)	(d)
(d) Disconnect Green Cable Np sensor	J16		A to C B to D	13.5-21.5 ohms	(e)	(g)

connector plug
 P16. Measure
 resistance of
 Np sensor at
 connector
 pins. Is the
 resistance
 correct?

(e) Replace
 green cable.

(f) Replace
 faulty EECU.

(g) Replace Np
 sensor.

(h) Continue
 to Operate.

* * * FOR CT7-2E1 MODIFIED TO SB 72-0013

TABLE 122A.. 006-27 - NP FAULT CH B

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
NOTE: To check if fault is cleared, it is necessary to motor the engine.						
(a) Check green cable and Np sensor coil for tightness. Any loose connectors found?	Green Cable				(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P2 green cable connector at EECU. Measure Np sensor coil resistance through green cable. Is the resistance correct?	EECU Np Sensor Green Cable	P2	50 to 27	13.5-21.5 ohms	(f)	(d)
(d) Disconnect Np sensor connector plug P16. Measure resistance of Np sensor at connector pins. Is the resistance correct?	Green Cable Np Sensor	J16	A to C B to D	13.5-21.5 ohms	(e)	(g)
(e) Replace green cable.						
(f) Replace faulty EECU.						
(g) Replace Np sensor.						
(h) Continue to Operate.						

* * * FOR CT7-2E1

TABLE 123. 008-27 - NP DISAGREE FAULT 008-26 - TORQUE DISAGREE FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
--------------	---------------------------------	-------	------	-------	-----	----

NOTE: To check if fault is cleared, it is necessary to motor the engine.

- (a) Check Green Cable (b) (c1)
 green cable Blue Cable
 and Np sensor
 coil for
 tightness. Any
 loose
 connectors
 found?
- (b) Tighten (f) (c1)
 loose
 connector
 plugs. Fault
 cleared?
- (c1) Swap the Np Sensor (d) (c2)
 CH A Np Sensor
 with a known
 functioning
 sensor. Does
 the fault
 clear?
- (c2) Swap the Np Sensor (d) (e)
 CH B Np Sensor
 with a known
 functioning
 sensor. Does
 the fault
 clear?
- (d) Replace Np
 sensor.
- (e) Replace
 the EECU.
- (f) Continue
 to Operate.

TABLE 124. 007-016 - OIL FILTER BYPASS FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and Oil filter bypass switch. Any loose connector found?	Green Cable	P2 P4			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect EECU P2 green cable connector at EECU. Measure oil filter bypass switch resistance through green cable. Is the resistance correct?	EECU Oil Filter Bypass Switch Green Cable	P2	48 to 25	0.5-2.0 ohms	(f)	(d)
(d) Disconnect oil filter bypass switch connector at P4 Measure resistance of oil filter bypass switch	Green Cable Oil Filter Bypass Switch	J4	1 to 2	0.2 ohms max	(e)	(g)

at connector pins. Is the resistance correct?
 (e) Replace green cable.
 (f) Replace faulty EECU.
 (g) Replace Oil Filter Bypass Switch.
 (h) Continue to Operate.

TABLE 125. 007-25 LOW OIL PRESSURE FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and Low Oil Pressure switch. Any loose connector found?	Blue Cable	P1 P8			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure low oil pressure switch resistance through blue cable. Is the resistance correct?	EECU Low Oil Pressure Switch Blue Cable	P1	72 to 56	0.5-3 ohms	(f)	(d)
(d) Disconnect low oil pressure switch connector at P8 Measure resistance of low oil pressure switch at connector pins. Is the resistance correct?	Blue Cable Low Oil Pressure Switch	J8	1 to 2	0.5-3 ohms	(e)	(g)
(e) Replace blue cable.						
(f) Replace faulty EECU.						
(g) Replace low oil pressure Switch.						
(h) Continue to Operate.						

TABLE 126. 005-20 OIL TEMPERATURE FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and Oil Temperature Sensor. Any loose connector found?	Blue Cable	P1 P6			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure Oil Temperature Sensor resistance through blue cable. Is the resistance correct?	EECU Oil Temperature Sensor Blue Cable	P1	38 to 37	Within limits of resistance versus temperature curve (TEST)	(f)	(d)
(d) Disconnect Oil Temperature Sensor connector at P6 Measure resistance of Oil Temperature Sensor at connector pins. Is the resistance correct?	Blue Cable Oil Temperature Sensor	J6	1 to 2	Within limits of resistance versus temperature curve (TEST)	(e)	(g)
(e) Replace blue cable.						
(f) Replace faulty EECU.						
(g) Replace Oil Temperature Sensor.						
(h) Continue to Operate.						

TABLE 127. 006-15 OIL PRESSURE FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and Oil Pressure Sensor. Any loose connector found?	Green Cable	P2 P9			(b)	(c)
(b) Tighten loose connector					(h)	(c)

plugs. Fault cleared?

(c) Disconnect EECU P2 74 to 79 1600 ohms min. (f) (d)
 P2 green cable Oil Pressure 75 to 77 2500 ohms max.

connector at Sensor
 EECU. Measure Green Cable
 Oil Pressure
 Sensor
 resistance
 through green
 cable. Is the
 resistance
 correct?

(d) Disconnect Green Cable (e) (g)
 Oil Pressure Oil Pressure
 Sensor Sensor

connector at
 P9 Measure
 resistance of
 Oil Pressure
 Sensor at
 connector
 pins. Is the
 resistance
 correct?

- Oil pressure J9 1 to 3 1600 ohms min.
 sensor
 excitation
 circuit

- Oil pressure J9 2 to 4 2500 ohms max.
 sensor output
 circuit

(e) Replace green cable.

(f) Replace faulty EECU.

(g) Replace Oil Pressure Sensor.

(h) Continue to Operate.

TABLE 128. 003-28 ALTERNATOR POWER CH A FAULT 005-29 NG ALTERNATOR FAULT A

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
NOTE: To check if Ng Alternator fault is cleared, it is necessary to motor the engine.						
(a) Check green cable connector plug for looseness at EECU and Alternator. Any loose connector found?	Green Cable	P2 P30			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect EECU P2 green cable connector at EECU. Measure Alternator Winding A resistance through green cable. Is the resistance correct?	Green Cable	P2	7 to 8 7 to 9	1-3.7 ohms 1-3.7 ohms	(f)	(d)

(d) Disconnect Green Cable J30 3 to 11 1-3.7 ohms (e) (g)
 Alternator Alternator 3 to 12 1-3.7 ohms
 connector at
 P30 Measure
 resistance of
 Alternator
 Winding A at
 connector
 pins. Is the
 resistance
 correct?
 (e) Replace
 green cable.
 (f) Replace
 faulty EECU.
 (g) Replace
 Alternator.
 (h) Continue
 to Operate.

TABLE 129. 004-28 ALTERNATOR POWER CH B FAULT 006-29 NG ALTERNATOR FAULT B

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
NOTE: To check if Ng Alternator fault is cleared, it is necessary to motor the engine.						
(a) Check green cable connector plug for looseness at EECU and Alternator. Any loose connector found?	Green Cable	P2 P30			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect EECU P2 green cable connector at EECU. Measure Alternator Winding B resistance through green cable. Is the resistance correct?	EECU Alternator	P2	11 to 12 11 to 13	1-3.7 ohms 1-3.7 ohms	(f)	(d)
(d) Disconnect Alternator connector at P30 Measure resistance of Alternator Winding B at connector pins. Is the resistance correct?	Green Cable Alternator	J30	6 to 1 6 to 7	1-3.7 ohms 1-3.7 ohms	(e)	(g)
(e) Replace green cable.						
(f) Replace faulty EECU.						
(g) Replace Alternator.						
(h) Continue to Operate.						

TABLE 130. 008-29 NG ALTERNATOR DISAGREE FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
NOTE: To check if Ng Alternator fault is cleared, it is necessary to motor the engine.						
(a) Check green cable connector plug for looseness at EECU and Alternator. Any loose connector found?	Green Cable	P2 P30			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(f)	(c)
(c) Swap Alternator with known good alternator. Does the fault clear?	Alternator EECU				(e)	(d)
(d) Replace faulty EECU.						
(e) Replace Alternator.						
(f) Continue to Operate.						

TABLE 131. 001-24 VAPOR VENT OUTPUT CH A FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and FMU. Any loose connector found?	Blue Cable	P1 P19			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure FMU Vapor Vent circuit resistance through blue cable. Is the resistance correct?	EECU FMU Blue Cable	P1	5 to 6	675-1075 ohms	(f)	(d)
(d) Disconnect Vapor Vent connector at P19 Measure resistance of Vapor Vent circuit at connector pins. Is the resistance correct?	Blue Cable FMU	J19	27 to 28	675-1075 ohms	(e)	(g)
(e) Replace						

- blue cable.
- (f) Replace faulty EECU.
- (g) Replace FMU.
- (h) Continue to Operate.

TABLE 132. 001-27 IGNITION OUTPUT CH A FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and Ignition Exciter Any loose connector found?	Green Cable	P2 P20			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect EECU P2 green cable connector at EECU. Measure Ignition Exciter Green Cable resistance through green cable. Is the resistance correct?		P2	37 to 38	540-660 ohms	(f)	(d)
(d) Disconnect Ignition Exciter connector at P20. Measure resistance of Ignition Excitor circuit at connector pins. Is the resistance correct?	Green Cable Ignition Exciter	J20	4 to 5	540-660 ohms	(e)	(g)
(e) Replace green cable.						
(f) Replace faulty EECU.						
(g) Replace faulty Ignition Exciter.						
(h) Continue to Operate.						

TABLE 133. 002-27 IGNITION OUTPUT CH B FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and	Green Cable	P2 P20			(b)	(c)

Ignition
 Exciter Any
 loose
 connector
 found?

(b) Tighten
 loose
 connector
 plugs. Fault
 cleared? (h) (c)

(c) Disconnect EECU P2 35 to 36 540-660 ohms (f) (d)
 P2 green cable Ignition
 connector at Exciter
 EECU. Measure Green Cable
 Ignition
 Exciter
 resistance
 through green
 cable. Is the
 resistance
 correct?

(d) Disconnect Green Cable J20 2 to 7 540-660 ohms (e) (g)
 Ignition Ignition
 Exciter Exciter
 connector at
 P20. Measure
 resistance of
 Ignition
 Exciter
 circuit at
 connector
 pins. Is the
 resistance
 correct?

(e) Replace
 green cable.

(f) Replace
 faulty EECU.

(g) Replace
 faulty
 Ignition
 Exciter.

(h) Continue
 to Operate.

TABLE 134. 007-24 FUEL FILTER BYPASS FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and Fuel Filter Bypass Switch. Any loose connector found?	Blue Cable	P1 P3			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure Fuel Filter Bypass Switch resistance through blue cable. Is the	EECU Fuel Filter Bypass Switch Blue Cable	P1	75 to 76	<5 ohms	(f)	(d)

resistance correct?

- (d) Disconnect Blue Cable J3 1 to 2 <5 ohms (e) (g)
 Fuel Filter Fuel Filter
 Bypass Switch Bypass Switch
 connector at
 P3 Measure
 resistance of
 Fuel Filter
 Bypass Switch
 circuit at
 connector
 pins. Is the
 resistance
 correct?
 (e) Replace
 blue cable.
 (f) Replace
 faulty EECU.
 (g) Replace
 Fuel Filter
 Bypass Switch.
 (h) Continue
 to Operate.

TABLE 135. 006-20 CHIP DETECTOR FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and Chip Detector. Any loose connector found?	Green Cable	P2 P5			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect EECU P2 green cable connector at EECU. Measure Chip Detector resistance through green cable. Is the resistance correct?	EECU Chip Detector Green Cable	P2	65 to 66	1000-1020 ohms	(f)	(d)
(d) Disconnect Chip Detector connector at P5. Measure resistance of Chip Detector circuit at connector pins. Is the resistance correct?	Green Cable Chip Detector	J5	1 to 2	1000-1020 ohms	(e)	(g)
(e) Replace green cable.						
(f) Replace faulty EECU.						
(g) Replace Chip Detector.						
(h) Continue to Operate.						

TABLE 136. 001-23 ANTI-ICE OUTPUT CH A FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and Anti-Icing Start Bleed Valve Any loose connector found?	Blue Cable	P1 PY			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure Anti-Icing Start Bleed Valve resistance through blue cable. Is the resistance correct?	EECU Anti-Icing Start Bleed Valve Blue Cable	P1	3 to 4	20-56 ohms	(f)	(d)
(d) Disconnect Anti-Icing Start Bleed Valve connector at PY. Measure resistance of Anti-Icing Start Bleed Valve circuit at connector pins. Is the resistance correct?	Blue Cable Anti-Icing Start Bleed Valve	JY	1 to 2	20-56 ohms	(e)	(g)
(e) Replace blue cable.						
(f) Replace faulty EECU.						
(g) Replace Anti-Icing Start Bleed Valve.						
(h) Continue to Operate.						

TABLE 137. 002-23 ANTI-ICE OUTPUT CH B FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and Anti-Icing Start Bleed Valve Any loose connector found?	Green Cable	P1 PX			(b)	(c)

- (b) Tighten loose connector plugs. Fault cleared? (h) (c)
- (c) Disconnect EECU P2 green cable connector at EECU. Measure Anti-Icing Start Bleed Valve Green Cable Start Bleed Valve resistance through green cable. Is the resistance correct? P2 21 to 22 20-56 ohms (f) (d)
- (d) Disconnect Green Cable Anti-Icing Start Bleed Valve connector at PX. Measure resistance of Anti-Icing Start Bleed Valve circuit at connector pins. Is the resistance correct? JX 1 to 2 20-56 ohms (e) (g)
- (e) Replace green cable.
- (f) Replace faulty EECU.
- (g) Replace Anti-Icing Start Bleed Valve.
- (h) Continue to Operate.

TABLE 138. 001-22 ANTI-ICE SYSTEM CH A FAULT 002-22 ANTI-ICE SYSTEM CH B FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and Anti-Icing Start Bleed Valve Any loose connector found?	Green Cable				(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(f)	(c)
(c) Replace valve with known functioning valve. Does the fault clear?	FMU Anti-Icing Start Bleed Valve				(e)	(d)
(d) Replace FMU.						
(e) Replace Anti-Icing						

Start Bleed Valve.
 (f) Continue to Operate.

TABLE 139. 001-26 VG OUTPUT CH A FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and FMU. Any loose connector found?	Blue Cable	P1 P19			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure VG step motor resistance through blue cable. Is the resistance correct?	EECU FMU Blue Cable	P1	24 to 48 25 to 26	35-45 ohms 35-45 ohms	(f)	(d)
(d) Disconnect FMU connector at P19. Measure resistance of VG step motor circuit at connector pins. Is the resistance correct?	FMU Blue Cable	J19	23 to 24 25 to 26	35-45 ohms 35-45 ohms	(e)	(g)
(e) Replace blue cable.						
(f) Replace faulty EECU.						
(g) Replace FMU.						
(h) Continue to Operate.						

TABLE 140. 002-26 VG OUTPUT CH B FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and FMU. Any loose connector found?	Green Cable	P2 P18			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P2 green cable	EECU FMU	P2	30 to 3 1 to 2	35-45 ohms 35-45 ohms	(f)	(d)

connector at Green Cable
 EECU. Measure
 VG step motor
 resistance
 through green
 cable. Is the
 resistance
 correct?

(d) Disconnect Green Cable	J18	23 to 24	35-45 ohms	(e)	(g)
FMU connector at P18.	FMU	25 to 26	35-45 ohms		

Measure
 resistance of
 VG step motor
 circuit at
 connector
 pins. Is the
 resistance
 correct?

(e) Replace
 green cable.

(f) Replace
 faulty EECU.

(g) Replace
 FMU.

(h) Continue
 to Operate.

TABLE 141. 005-19 VG LVDT FAULT A

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and FMU. Any loose connector found?	Blue Cable	P1 P19			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure VG LVDT resistance through blue cable. Is the resistance correct?	EECU FMU Blue Cable	P1	31 to 32 53 to 69 54 to 69	70-105 ohms 135-175 ohms 135-175 ohms	(f)	(d)
(d) Disconnect FMU connector at P19. Measure resistance of VG LVDT circuit at connector pins. Is the resistance correct?	FMU Blue Cable	J19	14 to 15 16 to 17 18 to 17	70-105 ohms 135-175 ohms 135-175 ohms	(e)	(g)
(e) Replace blue cable.						
(f) Replace faulty EECU.						
(g) Replace FMU.						

(h) Continue to Operate.

TABLE 142. 006-19 VG LVDT FAULT B

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and FMU. Any loose connector found?	Green Cable	P2 P18			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect EECU P2 green cable connector at EECU. Measure VG LVDT resistance through green cable. Is the resistance correct?	EECU FMU Green Cable	P2	61 to 62 42 to 41 60 to 41	70-105 ohms 135-175 ohms 135-175 ohms	(f)	(d)
(d) Disconnect FMU connector at P18. Measure resistance of VG LVDT circuit at connector pins. Is the resistance correct?	FMU Green Cable	J18	14 to 15 16 to 17 18 to 17	70-105 ohms 135-175 ohms 135-175 ohms	(e)	(g)
(e) Replace green cable.						
(f) Replace faulty EECU.						
(g) Replace FMU.						
(h) Continue to Operate.						

TABLE 143. 008-21 VG LVDT DISAGREE FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and FMU. Any loose connector found?	Blue Cable	P1 P2 P19 P18			(b)	(c1)
(b) Tighten loose connector plugs. Fault cleared?					(j)	(c1)
(c1) Disconnect P1 blue cable connector at EECU. Measure	EECU FMU Blue Cable	P1	31 to 32 53 to 69 54 to 69	70-105 ohms 135-175 ohms 135-175 ohms	(h)	(c2)

VG LVDT
 resistance
 through blue
 cable. Is the
 resistance
 correct?

(c2)	EECU	P2	61 to 62	70-105 ohms	(h)	(d1)
Disconnect P2	FMU		42 to 41	135-175 ohms		
green cable	Green Cable		60 to 41	135-175 ohms		

connector at
 EECU. Measure
 VG LVDT
 resistance
 through green
 cable. Is the
 resistance
 correct?

(d1)	FMU	J19	14 to 15	70-105 ohms	(d2)	(i)
Disconnect FMU	Blue Cable		16 to 17	135-175 ohms		
connector at			18 to 17	135-175 ohms		

P19. Measure
 resistance of
 VG LVDT
 circuit at
 connector
 pins. Is the
 resistance
 correct?

(d2)	FMU	J18	14 to 15	70-105 ohms	(e1)	(i)
Disconnect FMU	Green Cable		17 to 17	135-175 ohms		
connector at			18 to 17	135-175 ohms		

P18. Measure
 resistance of
 VG LVDT
 circuit at
 connector
 pins. Is the
 resistance
 correct?

(e1)	Measure	Blue Cable	P1	31 to 14	<2 ohms	(e2)	(f)
continuity of			P19	32 to 15	<2 ohms		
blue cable for				53 to 16	<2 ohms		
VG LVDT				69 to 17	<2 ohms		
circuit pin				54 to 18	<2 ohms		

resistance. Is
 the resistance
 correct?

(e2)	Measure	Green Cable	P2	61 to 14	<2 ohms	(i)	(g)
continuity of			P18	62 to 15	<2 ohms		
green cable				42 to 16	<2 ohms		
for VG LVDT				41 to 17	<2 ohms		
circuit pin				60 to 18	<2 ohms		

resistance. Is
 the resistance
 correct?

(f)	Replace					(j)	(i)
blue cable. Is							
the fault							
cleared?							

(g)	Replace					(j)	(i)
green cable.							
Is the fault							
cleared?							

(h) Replace
 faulty EECU.

(i) Replace
 faulty FMU.

(j) Continue
 to Operate.

TABLE 144. 001-20 VG SYSTEM CH A FAULT 002-20 VG SYSTEM CH B FAULT

Electrical Check

**Possible
 Faulty**

Instructions	Component	Conn.	Pins	Value	YES	NO
(a) Check VG actuating linkage for mechanical damage, looseness or being stuck. If damaged, repair VG actuating linkage. Fault cleared?	VG Actuating Linkage				(d)	(b)
(b) Replace AISBV. Fault cleared?	AISBV				(d)	(c)
(c) Replace FMU.	FMU					
(d) Continue to Operate.						

TABLE 145. 005-28 NG FMU FAULT A

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
NOTE: To check if the fault is cleared, it is necessary to motor the engine.						
(a) Check blue cable connector plug for looseness at EECU and FMU. Any loose connector found?	Blue Cable	P1			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure FMU Ng resistance through blue cable. Is the resistance correct?	EECU FMU Blue Cable	P1	19 to 44	500-2000 ohms	(f)	(d)
(d) Disconnect FMU connector at P19. Measure resistance of FMU Ng circuit at connector pins. Is the resistance correct?	FMU Blue Cable	J19	1 to 2	500-2000 ohms	(e)	(g)
(e) Replace blue cable.						
(f) Replace faulty EECU.						
(g) Replace FMU.						
(h) Continue to Operate.						

TABLE 146. 006-28 NG FMU FAULT B

Electrical Check

Possible Faulty

Instructions	Component	Conn.	Pins	Value	YES	NO
NOTE: To check if the fault is cleared, it is necessary to motor the engine.						
(a) Check green cable connector plug for looseness at EECU and FMU. Any loose connector found?	Green Cable	P2 P18			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P2 green cable connector at EECU. Measure FMU Ng resistance through green cable. Is the resistance correct?	EECU Green Cable	P2	26 to 49	500-2000 ohms	(f)	(d)
(d) Disconnect FMU connector at P18. Measure resistance of FMU Ng circuit at connector pins. Is the resistance correct?	FMU Green Cable	J18	1 to 2	500-2000 ohms	(e)	(g)
(e) Replace green cable.						
(f) Replace faulty EECU.						
(g) Replace FMU.						
(h) Continue to Operate.						

TABLE 147. 008-28 NG FMU DISAGREE FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
NOTE: To check if the fault is cleared, it is necessary to motor the engine.						
(a) Check green cable connector plug for looseness at EECU and FMU. Any loose connector found?	P2 P18				(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(d)	(c)
(c) Replace FMU.						
(d) Continue to Operate.						

TABLE 148. 005-21 FUEL TEMP FAULT CH A

Electrical Check

Possible Faulty

Instructions	Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and FMU. Any loose connector found?	Blue Cable	P1 P19			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure Ng T-Fuel resistance through blue cable. Is the resistance correct?	EECU FMU Blue Cable	P1	36 to 57	66-178 ohms	(f)	(d)
(d) Disconnect FMU connector at P19. Measure resistance of Ng T-Fuel circuit at connector pins. Is the resistance correct?	FMU Blue Cable	J19	7 to 8	66-178 ohms	(e)	(g)
(e) Replace blue cable.						
(f) Replace faulty EECU.						
(g) Replace FMU.						
(h) Continue to Operate.						

TABLE 149. 006-21 FUEL TEMP FAULT CH B

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and FMU. Any loose connector found?	Green Cable	P2 P18			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P2 green cable connector at EECU. Measure Ng T-Fuel resistance through green cable. Is the resistance correct?	EECU FMU Green Cable	P2	67 to 76	66-178 ohms	(f)	(d)
(d) Disconnect FMU		J18	7 to 8	66-178 ohms	(e)	(g)

FMU connector Green Cable
 at P18.
 Measure
 resistance of
 Ng T-Fuel
 circuit at
 connector
 pins. Is the
 resistance
 correct?
 (e) Replace
 green cable.
 (f) Replace
 faulty EECU.
 (g) Replace
 FMU.
 (h) Continue
 to Operate.

TABLE 150. 008-22 FUEL TEMP DISAGREE FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and FMU Any loose connector found?	Blue Cable	P1 P2 P19 P18			(b)	(c)
(b) Tighten loose connector plugs. Is the fault cleared?					(e)	(c)
(c) Replace the FMU. Is the fault cleared?	FMU				(e)	(d)
(d) Replace the EECU.	EECU					
(e) Continue to Operate.						

TABLE 151. 005-18 WF LVDT FAULT CH A

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and FMU. Any loose connector found?	Blue Cable	P1 P19			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure WF LVDT resistance through blue cable. Is the	EECU FMU Blue Cable	P1	51 to 52 67 to 77 68 to 77	66-100 ohms 240-500 ohms 240-500 ohms	(f)	(d)

resistance correct?

(d) Disconnect FMU connector at P19.	J19	9 to 10 11 to 12 13 to 12	66-100 ohms 240-500 ohms 240-500 ohms	(e)	(g)
--------------------------------------	-----	---------------------------------	---	-----	-----

Measure resistance of Wf LVDT circuit at connector pins. Is the resistance correct?

(e) Replace blue cable.

(f) Replace faulty EECU.

(g) Replace FMU.

(h) Continue to Operate.

TABLE 152. 006-18 WF LVDT FAULT CH B

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and FMU. Any loose connector found?	Green Cable	P2 P18			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P2 green cable connector at EECU. Measure Wf LVDT resistance through green cable. Is the resistance correct?	EECU FMU Green Cable	P2	14 to 39 40 to 15 59 to 15	66-100 ohms 240-500 ohms 240-500 ohms	(f)	(d)
(d) Disconnect FMU connector at P18. Measure resistance of Wf LVDT circuit at connector pins. Is the resistance correct?	FMU Green Cable	J18	9 to 10 11 to 12 13 to 12	66-100 ohms 240-500 ohms 240-500 ohms	(e)	(g)
(e) Replace green cable.						
(f) Replace faulty EECU.						
(g) Replace FMU.						
(h) Continue to Operate.						

TABLE 153. 008-20 WF LVDT DISAGREE FAULT

Electrical Check

Possible

Instructions	Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and FMU. Any loose connector found?	Blue Cable Green Cable	P1 P2 P19 P18			(b)	(c1)
(b) Tighten loose connector plugs. Fault cleared?					(j)	(c1)
(c1) Disconnect P1 blue cable connector at EECU. Measure VG LVDT resistance through blue cable. Is the resistance correct?	EECU FMU Blue Cable	P1	51 to 52 67 to 77 68 to 77	66-100 ohms 240-500 ohms 240-500 ohms	(h)	(c2)
(c2) Disconnect P2 green cable connector at EECU. Measure VG LVDT resistance through green cable. Is the resistance correct?	EECU FMU Green Cable	P2	14 to 39 40 to 15 59 to 15	66-100 ohms 240-500 ohms 240-500 ohms	(h)	(d1)
(d1) Disconnect FMU connector at P19. Measure resistance of VG LVDT circuit at connector pins. Is the resistance correct?	FMU Blue Cable	J19	9 to 10 11 to 12 13 to 12	66-100 ohms 240-500 ohms 240-500 ohms	(d2)	(i)
(d2) Disconnect FMU connector at P18. Measure resistance of VG LVDT circuit at connector pins. Is the resistance correct?	FMU Green Cable	J18	9 to 10 11 to 12 13 to 12	66-100 ohms 240-500 ohms 240-500 ohms	(e1)	(i)
(e1) Measure continuity of blue cable for VG LVDT circuit pin resistance. Is the resistance correct?	Blue Cable	P1 P19	51 to 9 52 to 10 67 to 11 77 to 12 68 to 13	<2 ohms <2 ohms <2 ohms <2 ohms <2 ohms	(e2)	(f)
(e2) Measure continuity of green cable for VG LVDT circuit pin resistance. Is the resistance correct?	Green Cable	P2 P18	14 to 9 39 to 10 40 to 11 15 to 12 59 to 13	<2 ohms <2 ohms <2 ohms <2 ohms <2 ohms	(i)	(g)

- (f) Replace blue cable. Is the fault cleared? (j) (i)
- (g) Replace green cable. Is the fault cleared? (j) (i)
- (h) Replace faulty EECU.
- (i) Replace faulty FMU.
- (j) Continue to Operate.

TABLE 154. 001-25 WF OUTPUT CH A FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check blue cable connector plug for looseness at EECU and FMU. Any loose connector found?	Blue Cable	P1 P19			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect P1 blue cable connector at EECU. Measure Wf step motor resistance through blue cable. Is the resistance correct?	EECU FMU Blue Cable	P1	22 to 46 23 to 47	37-75 ohms 37-75 ohms	(f)	(d)
(d) Disconnect FMU connector at P19. Measure resistance of Wf step motor circuit at connector pins. Is the resistance correct?	FMU Blue Cable	J19	19 to 20 21 to 22	37-75 ohms 37-75 ohms	(e)	(g)
(e) Replace blue cable.						
(f) Replace faulty EECU.						
(g) Replace FMU.						
(h) Continue to Operate.						

TABLE 155. 002-25 WF OUTPUT CH B FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and	Green Cable	P2 P18			(b)	(c)

FMU. Any loose connector found?						
(b) Tighten loose connector plugs. Fault cleared?					(h)	(c)
(c) Disconnect EECU P2 green cable connector at EECU. Measure Wf step motor resistance through green cable. Is the resistance correct?	P2	32 to 5	37-75 ohms		(f)	(d)
		31 to 4	37-75 ohms			
(d) Disconnect Green Cable FMU connector at P18. Measure resistance of Wf step motor circuit at connector pins. Is the resistance correct?	J18	19 to 20	37-75 ohms		(e)	(g)
		21 to 22	37-75 ohms			
(e) Replace green cable.						
(f) Replace faulty EECU.						
(g) Replace FMU.						
(h) Continue to Operate.						

TABLE 156. 001-21 WF SYSTEM CH A FAULT 002-21 WF SYSTEM CH B FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check green cable connector plug for looseness at EECU and FMU. Any loose connector found?	Green Cable	P2 P18			(b)	(c)
(b) Tighten loose connector plugs. Fault cleared?					(d)	(c)
(c) Replace FMU.	FMU					
(d) Continue to Operate.						

TABLE 157. 009-27 OEI LIMITS SELECT SWITCH FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Disconnect aircraft P1 connector at EECU of both engines. Depress switch on pilot	EECU Aircraft Wiring	Aircraft P1	45 to 9	<150 ohms	(b)	(e)

collective and while depressed check between pins 45 and 9 on both engines. Measure the resistance. Is the resistance correct?

(b) Release the switch and check pins. Open circuit? EECU Aircraft P1 Aircraft P1 45 to 9 >100K ohms (c) (e)

(c) Replace the EECU on Engine 1. Does the fault clear? (d) (f)

(d) Replace the EECU on Engine 2.

(e) Troubleshoot aircraft circuit for faulty engine.

(f) Replace faulty EECU permanently and continue to operate.

TABLE 158. 001-15 SIF FAULT CH A

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the circuit breakers on both channels of the FADEC. Put the SIF switch into the STOP position. At Aircraft P1 looking toward the aircraft, measure the resistance in the STOP, IDLE and FLY circuits. Are both IDLE and FLY open circuits and STOP closed circuit?	Aircraft EECU	Aircraft P1	31 to 79 77 to 79 78 to 79	<150 ohms >100K ohms >100K ohms	(b)	(d)
(b) Put the SIF switch into the IDLE Position. Measure the resistance in the STOP circuit and IDLE circuit. Is STOP open and IDLE closed?	Aircraft EECU	Aircraft P1	31 to 79 77 to 79	>100K ohms <150 ohms	(c)	(d)
(c) Put the SIF switch	Aircraft EECU	Aircraft P1	78 to 79	<150 ohms	(e)	(d)

into the FLY Position. Measure the resistance in the FLY circuit. Is it closed?

(d) Troubleshoot using Aircraft Maintenance Manual.

(e) Replace the EECU.

TABLE 159. 002-15 SIF FAULT CH B

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the circuit breakers on both channels of the FADEC. Put the SIF switch into the STOP position. At Aircraft P2 looking toward the aircraft, measure the resistance in the STOP, IDLE and FLY circuits. Are both IDLE and FLY open circuits and STOP closed circuit?	Aircraft EECU	Aircraft P2	31 to 27 55 to 27 11 to 27	<150 ohms >100K ohms >100K ohms	(b)	(d)
(b) Put the SIF switch into the IDLE Position. Measure the resistance in the STOP circuit and IDLE circuit. Is STOP open and IDLE closed?	Aircraft EECU	Aircraft P2	31 to 27 55 to 27	>100K ohms <150 ohms	(c)	(d)
(c) Put the SIF switch into the FLY Position. Measure the resistance in the FLY circuit. Is it closed?	Aircraft EECU	Aircraft P2	11 to 27	<150 ohms	(e)	(d)
(d) Troubleshoot using Aircraft Maintenance Manual.						
(e) Replace the EECU.						

TABLE 160. 001-16 ENGINE OUT SIGNAL FAULT CH A FAULT

Electrical Check
 Possible Faulty

Instructions	Component	Conn.	Pins	Value	YES	NO
(a) Pull the circuit breakers on both channels of the FADEC. At Aircraft P1 looking toward the aircraft, measure the resistance of the Engine Out circuit. Is the resistance correct?	Aircraft EECU	Aircraft P1	3 to 4	310-625 ohms	(b)	(c)
(b) Replace the EECU.						
(c) Troubleshoot using Aircraft Maintenance Manual.						

TABLE 161. 002-16 ENGINE OUT SIGNAL FAULT CH B FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the circuit breakers on both channels of the FADEC. At Aircraft P2 looking toward the aircraft, measure the resistance of the Engine Out circuit. Is the resistance correct?	Aircraft EECU	Aircraft P2	4 to 5	310-625 ohms	(b)	(c)
(b) Replace the EECU.						
(c) Troubleshoot using Aircraft Maintenance Manual.						

TABLE 162. 001-28 START OUTPUT CH A FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the circuit breakers on both channels of the FADEC. At Aircraft P1 looking toward the aircraft, measure the resistance of the Start Output circuit. Is the resistance correct?	Aircraft EECU	Aircraft P1	5 to 6	310-625 ohms	(b)	(c)
(b) Replace the EECU.						
(c) Troubleshoot						

using Aircraft
 Maintenance
 Manual.

TABLE 163. 002-28 START OUTPUT CH B FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the circuit breakers on both channels of the FADEC. At Aircraft P2 looking toward the aircraft, measure the resistance of the Start Output circuit. Is the resistance correct?	Aircraft EECU	Aircraft P2	2 to 3	310-625 ohms	(b)	(c)
(b) Replace the EECU.						
(c) Troubleshoot using Aircraft Maintenance Manual.						

TABLE 164. 003-22 CROSS ENGINE BUS TX CH A FAULT 003-23 ARINC TX1 CH A FAULT 004-23 ARINC TX1 CH B FAULT 004-22 CROSS ENGINE BUS TX CH B

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Replace the EECU.	EECU					

TABLE 165. 003-25 ARINC RX1 CH A FAULT 004-25 ARINC RX1 CH B FAULT 003-24 ARINC RX2 CH A FAULT 004-24 ARINC RX2 CH B FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the circuit breakers on both channels of the FADEC. Do both ARINC RX1 faults display?	Transmission from AMMC 1 - Aircraft				(g)	(b)
(b) Do both ARINC RX2 faults display?	Transmission from AMMC 2 - Aircraft				(g)	(c)
(c) Does only one RX1 or RX2 display on channel A?	EECU Aircraft				(d)	(e)
(d) Leave aircraft connector AllP1 or A12P1 connected for engine 1 or engine 2 respectively, at EECU. Disconnect aircraft	EECU Aircraft	Aircraft P265 or P266 for engine 1 or engine 2 respectively	51 to 67 53 to 68	<50 ohms or >100K ohms	(f)	(g)

connector P265
 or P266, for
 engine 1 or
 engine 2
 respectively,
 on engine side
 firewall.
 Looking toward
 the EECU,
 measure the
 resistance. Is
 the resistance
 correct?

(e) One RX1 or EECU
 RX2 displays Aircraft
 on channel B.
 Leave EECU
 aircraft
 connector
 AllP2 or Al2P2
 connected for
 engine 1 or
 engine 2
 respectively,
 at EECU.

Aircraft P267 58 to 71
 or P268 for 59 to 72
 engine 1 or
 engine 2
 respectively

<50 ohms or
 >100K ohms

(f)

(g)

Disconnect
 aircraft
 connector P267
 or P268, for
 engine 1 or
 engine 2
 respectively,
 on engine side
 of LPU or
 firewall.
 Looking toward
 the EECU,
 measure the
 resistance. Is
 the resistance
 correct?

(f) Replace
 the EECU.

(g)
 Troubleshoot
 aircraft using
 Aircraft
 Maintenance
 Manual.

TABLE 166. 003-29 28 VDC CH A FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the breakers on both FADEC channels and disconnect EECU at Aircraft P1. Put the breakers back on and looking toward the aircraft, measure the voltage. Disconnect the breaker again. Is the voltage correct?	EECU Aircraft	Aircraft P1	21 to 22	28 volts	(b)	(c)
(b) Replace the EECU.						
(c)						

Troubleshoot the aircraft using the Aircraft Maintenance Manual.

TABLE 167. 004-29 28 VDC CH B FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the breakers on both FADEC channels and disconnect EECU at Aircraft P2. Put the breakers back on and looking toward the aircraft, measure the voltage. Disconnect the breaker again. Is the voltage correct?	EECU Aircraft	Aircraft P2	12 to 13	28 volts	(b)	(c)
(b) Replace the EECU.						
(c) Troubleshoot the aircraft using the Aircraft Maintenance Manual.						

TABLE 168. 007-22 CHANNEL A DETECTS FAULT IN BUS FROM CHANNEL B OF THE OTHER ENGINE
 007-21 CHANNEL B DETECTS FAULT IN BUS FROM CHANNEL A OF THE OTHER ENGINE
 007-14 CHANNEL B DETECTS FAULT IN BUS FROM CHANNEL B OF THE OTHER ENGINE
 007-29 CHANNEL A DETECTS FAULT IN BUS FROM CHANNEL A OF THE OTHER ENGINE

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Does only one fault appear alone?					(g)	(b)
(b) Are fault word 7 bits 21 and 29 present?					(c)	(d)
(c) Pull the breakers on both channels of the FADEC on the engine that saw the fault. At Aircraft P1 looking towards the aircraft, measure the resistance. Is the resistance correct?	EECU Aircraft	Aircraft P1	58 to 71	158-202 ohms	(g)	(e)
(d) Fault word 7 bits 22 and 14 are present. Pull the breakers	EECU Aircraft	Aircraft P2	10 to 37	158-202 ohms	(g)	(f)

on both channels of the FADEC on the engine that saw the fault. At Aircraft P2 looking towards the aircraft, measure the resistance. Is the resistance correct?

(e) On the other engine, disconnect at Aircraft P1 looking towards the aircraft and measure the resistance. Is the resistance correct?	EECU Aircraft	Aircraft P1	58 to 71	158-202 ohms	(g)	(h)
--	------------------	-------------	----------	--------------	-----	-----

(f) On the other engine, disconnect at Aircraft P2 looking towards the aircraft and measure the resistance. Is the resistance correct?	EECU Aircraft	Aircraft P2	10 to 37	158-202 ohms	(g)	(h)
--	------------------	-------------	----------	--------------	-----	-----

(g) Replace the faulty EECU.

(h) Troubleshoot using Aircraft Maintenance Manual.

TABLE 169. 007-28 WF ON/OFF DISCRETE FAULT CH A

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the breakers on both channels of the FADEC. Set SIF switch to STOP. At Aircraft P1 looking toward the aircraft, measure the resistance. Is fuel OFF closed circuit and Fuel ON open circuit?	EECU Aircraft	Aircraft P1	31 to 79 32 to 79	<150 ohms >100K ohms	(b)	(e)
(b) Set SIF switch to IDLE. Is fuel OFF an open circuit and Fuel ON a closed circuit?	EECU Aircraft	Aircraft P1	31 to 79 32 to 79	>100K ohms <150 ohms	(c)	(e)
(c) Set SIF switch to IDLE. Is fuel	EECU Aircraft	Aircraft P1	31 to 79 32 to 79	>100K ohms <150 ohms	(d)	(e)

OFF an open circuit and Fuel On a closed circuit?
 (d) Replace the EECU.
 (e) Troubleshoot the aircraft using Aircraft Maintenance Manual.

TABLE 170. 007-20 WF ON/OFF DISCRETE FAULT CH B

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the breakers on both channels of the FADEC. Set SIF switch to STOP. At Aircraft P2 looking toward the aircraft, measure the resistance. Is fuel OFF closed circuit and Fuel ON open circuit?	EECU Aircraft	Aircraft P2	31 to 27 32 to 27	<150 ohms >100K ohms	(b)	(e)
(b) Set SIF switch to IDLE. Is fuel OFF an open circuit and Fuel ON a closed circuit?	EECU Aircraft	Aircraft P2	31 to 27 32 to 27	>100K ohms <150 ohms	(c)	(e)
(c) Set SIF switch to IDLE. Is fuel OFF an open circuit and Fuel On a closed circuit?	EECU Aircraft	Aircraft P2	31 to 27 32 to 27	>100K ohms <150 ohms	(d)	(e)
(d) Replace the EECU. (e) Troubleshoot the aircraft using Aircraft Maintenance Manual.						

TABLE 171. 008-14 AI POSITION FB DISAGREEMENT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Disconnect engine P1 blue cable connector at EECU. Measure the AISBV resistance through the blue cable. Is the resistance correct?	EECU AISBV	P1	41 to 42	>100K ohms	(b)	(c)

- (b) Disconnect EECU P2 57 to 58 <50 ohms (f) (c)
 engine P2 AISBV
 green cable
 connector at
 EECU. Measure
 the AISBV
 resistance
 through the
 green cable.
 Is the
 resistance
 correct?
- (c) Disconnect AISBV JY 3 to 4 >100K ohms (d) (e)
 AISBV at PY Harness
 and measure
 the
 resistance. Is
 the resistance
 correct?
- (d) Disconnect AISBV JX 3 to 4 <50 ohms (g) (e)
 AISBV at PX Harness
 and measure
 the
 resistance. Is
 the resistance
 correct?
- (e) Replace
 the AISBV.
- (f) Replace
 the EECU.
- (g) Replace
 the harness.

TABLE 172. 008-19 COLLECTIVE DISAGREE FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
Collective signals to CHA and CHB do not agree. Check aircraft maintenance manual and calibration.	Aircraft					

TABLE 173. 009-20 LOCAL ENGINE CHANNEL A AEO LIMIT SELECTION FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the breakers on both channels of the FADEC. Depress AEO button and check pins. Is the circuit closed?	EECU Aircraft	Aircraft P1	8 to 9	<150 ohms	(b)	(d)
(b) Release AEO button and check pins. Is the circuit open?	EECU Aircraft	Aircraft P1	8 to 9	>100K ohms	(c)	(d)
(c) Replace the EECU.						
(d) Troubleshoot the aircraft using Aircraft Maintenance Manual.						

TABLE 174. 009-21 LOCAL ENGINE CHANNEL B AEO LIMIT SELECTION FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the breakers on both channels of the FADEC. Depress AEO button and check pins. Is the circuit closed?	EECU Aircraft	Aircraft P2	38 to 24	<150 ohms	(b)	(d)
(b) Release AEO button and check pins. Is the circuit open?	EECU Aircraft	Aircraft P2	38 to 24	>100K ohms	(c)	(d)
(c) Replace the EECU.						
(d) Troubleshoot the aircraft using Aircraft Maintenance Manual.						

TABLE 175. 009-22 SIF DISAGREEMENT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
SIF input from one engine does not agree with SIF input to other engine. Troubleshoot aircraft maintenance manual.	Aircraft					

TABLE 176. 009-23 AI REQUEST DISAGREEMENT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the breakers on both channels of the FADEC. Set anti-ice switch to OFF and check pins. Is the circuit closed?		Aircraft P1 Aircraft P2	37 to 52 28 to 1	<150 ohms	(b)	(d)
(b) Set anti-ice to ON and check pins. Is the circuit open?		Aircraft P1 Aircraft P2	37 to 52 28 to 1	>100K ohms	(c)	(d)
(c) Replace EECU.						
(d) Troubleshoot aircraft using aircraft maintenance manual.						

TABLE 177. 009-24 TRAINING INPUT DISAGREEMENT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the breakers on both FADEC channels. With the training switch depressed, on engine 1 disconnect at connector aircraft P1. Check pins. Is it a closed circuit?	Aircraft	Aircraft P1	35 to 36	<150 ohms	(b)	(g)
(b) With the training switch depressed, on engine 2 disconnect at connector aircraft P1. Check pins. Is it a closed circuit?	Aircraft	Aircraft P1	57 to 36	<150 ohms	(c)	(g)
(c) With the training switch released, on engine 1 disconnect connector at aircraft P1. Check pins. Is it a closed circuit?	Aircraft	Aircraft P1	35 to 36	>100K ohms	(d)	(g)
(d) With the training switch released, on engine 2 disconnect connector aircraft P1. Check pins. Is it a closed circuit?	EECU Aircraft	Aircraft P1	57 to 36	>100K ohms	(e)	(g)
(e) Replace EECU on engine 1. Fault cleared?	EECU Aircraft				(h)	(f)
(f) Replace the EECU on engine 2. Fault cleared?	EECU Aircraft				(h)	(g)
(g) Troubleshoot aircraft via aircraft maintenance manual.						
(h) Replace EECU.						

TABLE 178. 001-29 IGNITION, STARTER, OR ENGINE OUT RELAY FAULT CH A

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Is fault	EECU				(h)	(b)

accompanied by
 EECU Isolation
 Flag CH A
 fault?

(b) Disconnect EECU P2 green cable connector at EECU. Measure ignition circuit resistance through the green cable. Is the resistance correct?	J2	38 to 37 38 to connector shell	>100K ohms >100K ohms	(f)	(c)
--	----	---	--------------------------	-----	-----

(c) Disconnect Ignition ignition exciter at P20. Measure resistance of exciter at connector pins. Is the resistance correct?	J20	4 to 5 4 to connector shell	>100K ohms >100K ohms	(d)	(e)
---	-----	-----------------------------------	--------------------------	-----	-----

(d) Replace
the green
cable.

(e) Replace
the ignition
exciter.

(f) Pull the breakers for both FADEC channels. At aircraft P1 looking toward the aircraft, measure the resistance of the starter circuit. Is the resistance correct?	EECU Aircraft	Aircraft P1	6 to 5 6 to connector shell	>100K ohms >100K ohms	(g)	(i)
--	------------------	-------------	-----------------------------------	--------------------------	-----	-----

(g) With the breakers still pulled, measure the engine out circuit on aircraft P1. Is the resistance correct?	EECU Aircraft	Aircraft P1	4 to 3 4 to connector shell	>100K ohms >100K ohms	(h)	(i)
--	------------------	-------------	-----------------------------------	--------------------------	-----	-----

(h) Replace
the EECU.

(i)
Troubleshoot
aircraft using
aircraft
maintenance
manual.

TABLE 179. 002-29 IGNITION, STARTER, OR ENGINE OUT RELAY FAULT CH B

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Is fault accompanied by EECU Isolation Flag CH B fault?	EECU				(h)	(b)

- (b) Disconnect EECU J2 36 to 35 >100K ohms (f) (c)
 P2 green cable Ignition 36 to >100K ohms
 connector at Exciter connector
 EECU. Measure Green Cable shell
 ignition
 circuit
 resistance
 through the
 green cable.
 Is the
 resistance
 correct?
- (c) Disconnect Ignition J20 2 to 7 >100K ohms (d) (e)
 ignition Exciter 2 to connector >100K ohms
 exciter at Green Cable shell
 P20. Measure
 resistance of
 exciter at
 connector
 pins. Is the
 resistance
 correct?
- (d) Replace
 the green
 cable.
- (e) Replace
 the ignition
 exciter.
- (f) Pull the EECU Aircraft P2 2 to 3 >100K ohms (g) (i)
 breakers for Aircraft 2 to connector >100K ohms
 both FADEC shell
 channels. At
 aircraft P2
 looking toward
 the aircraft,
 measure the
 resistance of
 the starter
 circuit. Is
 the resistance
 correct?
- (g) With the EECU Aircraft P2 4 to 5 >100K ohms (h) (i)
 breakers still Aircraft 4 to connector >100K ohms
 pulled, shell
 measure the
 engine out
 circuit on
 aircraft P2.
 Is the
 resistance
 correct?
- (h) Replace
 the EECU.
- (i)
 Troubleshoot
 aircraft using
 aircraft
 maintenance
 manual.

TABLE 180. 008-18 TEST CELL PAL DISAGREE FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
Troubleshoot the test cell and calibration of the PAL.	Test Cell					

TABLE 181. 005-16 TEST CELL PAL FAULT A

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO

Instructions	Component	Conn.	Pins	Value	YES	NO
(a) Pull the breakers for both FADEC channels. Disconnect EECU at aircraft P1 and looking toward the aircraft, measure the resistance. Is the resistance correct?	EECU Test Cell	Aircraft P1	29 to 28	150-100K ohms	(b)	(c)
			1 to 2	150-100K ohms		
			30 to 2	150-100K ohms		
			29 to connector	>100K ohms		
			back-shell	>100K ohms		
			28 to connector	>100K ohms		
			back-shell	>100K ohms		
			1 to connector	>100K ohms		
			back-shell	>100K ohms		
			2 to connector	>100K ohms		
			back-shell	>100K ohms		
			30 to connector	>100K ohms		
			back-shell	>100K ohms		
			(b) Change the EECU.			
(c) Troubleshoot the test cell.						

TABLE 182. 006-16 TEST CELL PAL FAULT B

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the breakers for both FADEC channels. Disconnect EECU at aircraft P2 and looking toward the aircraft, measure the resistance. Is the resistance correct?	EECU Test Cell	Aircraft P2	65 to 76	150-100K ohms	(b)	(c)
			29 to 51	150-100K ohms		
			30 to 51	150-100K ohms		
			65 to connector	>100K ohms		
			back-shell	>100K ohms		
			76 to connector	>100K ohms		
			back-shell	>100K ohms		
			29 to connector	>100K ohms		
			back-shell	>100K ohms		
			51 to connector	>100K ohms		
			back-shell	>100K ohms		
			30 to connector	>100K ohms		
			back-shell	>100K ohms		
			(b) Change the EECU.			
(c) Troubleshoot the test cell.						

TABLE 183. 009-18 CRANK SIGNAL DISAGREE FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull the breakers for both FADEC channels. Hold the SIF switch in the crank position. Looking toward the aircraft, measure the resistance on aircraft P1 and P2. Are the resistances correct?	EECU Aircraft	Aircraft P1	56 to 79	<150 ohms	(b)	(d)
		Aircraft P2	47 to 27	<150 ohms		
(b) Release the SIF from	EECU Aircraft	Aircraft P1	56 to 79	>100K ohms	(c)	(d)
		Aircraft P2	47 to 27	>100K ohms		

the crank position. Measure the resistance on aircraft Pland P2. Are the resistances correct?

(c) Replace EECU.

(d) Troubleshoot the aircraft.

TABLE 184. 009-29 NR SIGNAL DISAGREE FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
Two Nr channels from the aircraft to the EECU disagree. Troubleshoot the aircraft.	Aircraft					

TABLE 185. 009-28 LOAD SHARE SELECTION SWITCH DISAGREE BETWEEN ENGINES FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
Load share switch signal disagrees from aircraft to engines. Troubleshoot aircraft.	Aircraft					

TABLE 186. 009-26 LOAD SHARE SELECTION SWITCH LOCAL ENGINE DISAGREE FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Pull breakers for both FADEC channels. Put the load share switch in the torque position. Looking toward the aircraft, measure the resistance at aircraft P2. Are the resistances correct?		Aircraft P2	63 to 14 46 to 14	<150 ohms >100K ohms	(b)	(d)
(b) Put the load share switch in the ITT position. Measure the resistance at aircraft P2. Are the resistances correct?		Aircraft P2	63 to 14 46 to 14	>100K ohms <150 ohms	(c)	(d)
(c) Replace the EECU.						
(d) Troubleshoot						

aircraft using
 the Aircraft
 Maintenance
 Manual.

TABLE 187. 001-19 OVERSPEED SYSTEM TEST #1 CH A FAULT 001-17 OVERSPEED SYSTEM TEST #3
 CH A FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Are any other fault codes present?					(b)	(c)
(b) Correct other faults. Run engine on ground to idle and shutdown. Does the fault clear?					(j)	(c)
(c) Check EECU, blue cable, and FMU for loose connectors. Loose connectors found?	EECU FMU Blue Cable	P1 P19			(d)	(e)
(d) Tighten loose connectors. Fault cleared?	EECU FMU Blue Cable	P1 P19			(j)	(e)
(e) Disconnect P1 blue cable connector at EECU. Measure Overspeed Solenoid resistance through blue cable. Is the resistance correct?	EECU FMU Blue Cable	P1	1 to 2	7.8-21.8 ohms	(h)	(f)
(f) Disconnect FMU connector at P19. Measure resistance of Overspeed Solenoid circuit at connector pins. Is the resistance correct?	FMU Blue Cable	J19	3 to 4	7.8-21.8 ohms	(g)	(i)
(g) Replace blue cable.						
(h) Replace faulty EECU.						
(i) Replace FMU.						
(j) Continue to Operate.						

TABLE 188. 002-19 OVERSPEED SYSTEM TEST #1 CH B FAULT 002-17 OVERSPEED SYSTEM TEST #3
 CH B FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Are any					(b)	(c)

other fault codes present?

(b) Correct other faults. Run engine on ground to idle and shutdown. Does the fault clear? (j) (c)

(c) Check EECU, green cable, and FMU for loose connectors. Loose connectors found? EECU P2 FMU P18 Green Cable P18 (d) (e)

(d) Tighten loose connectors. Fault cleared? EECU P2 FMU P18 Green Cable (j) (e)

(e) Disconnect P2 greencable connector at EECU. Measure Overspeed Solenoid resistance through green cable. Is the resistance correct? EECU P2 FMU P18 Green Cable 19 to 20 7.8-21.8 ohms (h) (f)

(f) Disconnect FMU connector at P18. Measure resistance of Overspeed Solenoid circuit at connector pins. Is the resistance correct? FMU J18 Green Cable 3 to 4 7.8-21.8 ohms (g) (i)

(g) Replace green cable.

(h) Replace faulty EECU.

(i) Replace FMU.

(j) Continue to Operate.

TABLE 189. 001-18 OVERSPEED SYSTEM TEST #2 CH A FAULT 002-18 OVERSPEED SYSTEM TEST #2 CH B FAULT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Check EECU, green cable, blue cable, and FMU for loose connectors. Loose connectors found?	EECU Blue Cable Green Cable FMU	P1 P2 J18 J19			(b)	(c)
(b) Tighten loose connectors. Fault cleared?	EECU Blue Cable Green Cable FMU	P1 P2 J18 J20			(e)	(c)

- (c) Replace EECU (e) (d)
 the FMU. Run FMU
 engine on
 ground to idle
 and shutdown.
 Does the fault
 clear?
- (d) Replace
 the EECU.
- (e) Continue
 to Operate.

TABLE 190. 003-14 OVERSPEED SYSTEM TEST NOT COMPLETE CH A FAULT 004-14 OVERSPEED SYSTEM TEST NOT COMPLETE CH B FAULT

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Are any other fault codes present?					(b)	(c)
(b) Correct other faults. Run engine on ground to idle and shutdown. Does the fault clear?					(g)	(c)
(c) Check EECU, green cable, blue cable, and FMU for loose connectors. Loose connectors found?	EECU FMU Blue Cable Green Cable	P1 P2 P18 P19			(d)	(e)
(d) Tighten loose connectors. Run engine on ground to idle and shutdown. Fault cleared?	EECU FMU Blue Cable Green Cable	P1 P2 P18 P19			(g)	(e)
(e) Replace FMU. Run engine on ground to idle and shutdown. Fault Cleared?	FMU EECU				(g)	(f)
(f) Replace EECU.						
(g) Continue to Operate.						

TABLE 191. 005-17 COLLECTIVE FAULT A, 006-17 COLLECTIVE FAULT B, 007-15 NR FAULT CH B, 007-23 NR FAULT CH A

Electrical Check						
Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Troubleshoot using Aircraft Maintenance Manual. Is the resistance correct?						(b)
(b) Replace the EECU.						

TABLE 192. 001-25 ECU EXCEEDS TEMPERATURE LIMIT

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Are any other fault codes present?					(c)	(b)
(b) Did fault occur while engine was operating?					(f)	(c)
(c) Permit EECU to cool. Correct other faults. Run engine on ground to idle and shutdown. Does the fault clear?					(h)	(e)
(d) Permit EECU to cool. Run engine on ground to idle and shutdown. Does the fault clear?					(h)	(e)
(e) Replace EECU.						
(f) Is IPS Blower shaft sheared?					(g)	(e)
(g) Replace IPS Blower, fault cleared?					(h)	(e)
(h) Added Table 191, Table 192, and Table 193.						

TABLE 193. 001-29 OVERSPEED TEST NOT COMPLETED

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
(a) Follow troubleshooting for fault word 003-14 (Table 190).	Overspeed Test Not Completed					

* * * FOR CT7-2E1 MODIFIED TO SB 72-0013

TABLE 194. 005-26 TORQUE FAULT CH A

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
NOTE: To check if fault is cleared, it is necessary to motor the engine.						
(a) Check blue cable and Np sensor coil for tightness. Any loose connectors found?					(c)	(b)
(b) Check green cable and torque ID plug for tightness. Any loose connectors found?	Green Cable				(c)	(d)
(c) Tighten					(m)	(d)

loose
 connector
 plugs. Fault
 cleared?

(d) Disconnect EECU P1 16 to 17 13.5-21.5 ohms (i) (e)
 P1 blue cable Np Sensor
 connector at Blue Cable
 EECU. Measure
 Np sensor coil
 resistance
 through blue
 cable. Is the
 resistance
 correct?

(e) Disconnect Blue Cable J17 A to C 13.5-21.5 ohms (h) (j)
 Np sensor Np Sensor
 B to D
 connector plug
 P17. Measure
 resistance of
 Np sensor at
 connector
 pins. Is the
 resistance
 correct?

(f) Disconnect Green Cable P2 68 to 69 70-80 ohms for (i) (g)
 P2 green cable Torque ID Plug
 connector at
 EECU. Measure
 torque ID plug
 resistance
 through the
 green cable.
 Is the
 resistance
 correct?

(g) Disconnect Green Cable J34 A to B 70-79 ohms for (k) (l)
 torque ID plug Torque ID Plug
 P34. Measure
 resistance of
 torque ID plug
 at connector
 pins. Is the
 resistance
 correct?

(h) Replace
 blue cable.

(i) Replace
 EECU.

(j) Replace Np
 sensor.

(k) Replace
 green cable.

(l) Replace
 torque ID
 plug.

(m) Continue
 to Operate.

TABLE 195. 006-26 TORQUE FAULT CH B

Electrical Check

Instructions	Possible Faulty Component	Conn.	Pins	Value	YES	NO
NOTE: To check if fault is cleared, it is necessary to motor the engine.						
(a) Check green cable, torque ID plug, and Np sensor coil for tightness. Any loose connectors found?	Green Cable				(b)	(c)

(b) Tighten loose connector plugs. Fault cleared?					(k)	(c)
(c) Disconnect EECU P2 green cable connector at EECU. Measure Np sensor coil resistance through green cable. Is the resistance correct?	P2	50 to 27	13.5-21.5 ohms		(d)	(f)
(d) Disconnect Green Cable P2 green cable connector at EECU. Measure torque ID plug resistance through the green cable. Is the resistance correct?	P2	68 to 69	70-80 ohms for "-" plug; 90-110 ohms for "0" plug; 140-160 ohms for "+" plug		(h)	(e)
(e) Disconnect Green Cable torque ID plug P34. Measure resistance of torque ID plug at connector pins. Is the resistance correct?	J34	A to B	70-79 ohms for "-" plug; 95-105 ohms for "0" plug; 142-158 ohms for "+" plug		(g)	(i)
(f) Disconnect Green Cable Np sensor connector plug P16. Measure resistance of Np sensor at connector pins. Is the resistance correct?	J16	A to C B to D	13.5-21.5 ohms		(g)	(j)
(g) Replace green cable.						
(h) Replace EECU.						
(i) Replace torque ID plug.						
(j) Replace Np sensor.						
(k) Continue to Operate.						

GE Designated: - CONFIDENTIAL Subject to the restrictions on the media