

Maintenance Manual

SUPER KING AIR B300/B300C

B300 (FL-1 THRU FL-953, FL-955 THRU FL-1009, FL-1011 THRU FL-1030)

B300C (FM-1 THRU FM-65)

REVISION SUMMARY/HIGHLIGHTS
P/N 130-590031-11, Revision C4

1. General

- A. In this revision, the Super King Air B300/B300C Maintenance Manual chapters which have been revised or added are listed below with the Highlights of each change. Remove the affected pages and insert this Revision in accordance with the attached Instruction Page. Enter the revision number and the date inserted on the Record of Revisions page of this manual. The Highlights Page may be retained with the manual for future reference. Some sections have revised text and/or graphics which are indicated by a revision bar or highlighted text. All other sections have not been revised since the last revision.

2. Definition

- A. Columns
- (1) Chapter-Section-Subject - This column gives the manual location for each document in the revision.
 - (2) Document Title - This column gives the name of the document as it is given at the top of the actual document and in the Table of Contents.
 - (3) Description - This column gives a short description of the changes that have been made to that section in this revision.

3. Revision Information

- A. The following changes were made to the Super King Air B300/B300C Maintenance Manual. Sections referenced to other manuals listed in this maintenance manual (example 25-XX-XX AMM) may not be released at the time of this revision. All referenced sections will be released in their applicable manual as quickly as possible and will be noted within that manual's Revision Summary/Highlights section provided with each revision.

CHAPTER SECTION SUBJECT	DOCUMENT TITLE	ACTION
	Inspection Program Reformat General	<ul style="list-style-type: none"> • In this revision, the existing inspection program was reformatted into a Task-Based Inspection Program. • Inspection requirements remain unchanged unless otherwise noted in the Revision Highlights. • Task numbers, task titles, and zone information were added to the inspection requirements • Chapter 5 has been reorganized to better align with the new format. • All Chapter 5 sections have the current release date. • Changed instances of Year' intervals to the Calendar Month equivalent throughout the program.
Introduction	PUBLICATION TITLE PAGE	
Introduction	REVISION SUMMARY/HIGHLIGHTS	<ul style="list-style-type: none"> • Updated for Revision 4
Introduction	LIST OF EFFECTIVE PAGES	
Introduction	TABLE OF CONTENTS	
Introduction	LIST OF REVISIONS	<ul style="list-style-type: none"> • Added Revision C4 and the corresponding date.
Chapter 05	LIST OF EFFECTIVE PAGES	
Chapter 05	TABLE OF CONTENTS	

5-00-00	TIME LIMITS/MAINTENANCE CHECKS	<ul style="list-style-type: none"> Reformatted and revised for the newly formatted inspection program. Renamed and reorganized subsections for clarity. Revised Grace Period Statement to say "additional new requirements." Added inspection task information and inspection program layout information to the section. Revised Interval Tolerances to reflect new inspection program format.
5-10-00	INSPECTION PROGRAM DOCUMENTS	<ul style="list-style-type: none"> Added section to list out Inspection Phases and their associated interval for the task-based inspection program update.
5-10-01	INSPECTION TIME LIMITS	<ul style="list-style-type: none"> Added Inspection Time Limits to provide a summary of inspection tasks included in task-based inspection program inspection phases.
5-11-00	OVERHAUL AND REPLACEMENT SCHEDULE	<ul style="list-style-type: none"> Moved information from 5-11-00, 201 for inspection program reorganization. Updated table format. Inspections remain unchanged unless otherwise noted. Changed the intervals listed in years to months for consistency across the inspection program. Removed the requirement to replace the Firewall Shutoff Valve and listed the permitted leak rate in the Removal and Installation procedure for the valve. Removed the requirement to replace the Tachometer Generator N1 & N2 on condition from the list of scheduled replacements. Removed the requirement to replace the low pressure fuel boost pump on condition from the list of scheduled replacements. Removed the requirement to replace the oil cooler if contaminated and put the requirement in the Removal and Installation procedure for that component. Assigned task numbers and titles to the existing life-limited components. Added note to Table 3 and Task 25-60-00-9600.
05-11-00	OVERHAUL AND REPLACEMENT SCHEDULE	<ul style="list-style-type: none"> Move data to 05-11-00, 001 per inspection program update. Deleted empty section.
5-15-00	PRE-INSPECTION AND POST-INSPECTION CHECKS	<ul style="list-style-type: none"> Added section for Phase Inspection Pre and Post Inspection Procedures.
05-21-00	SCHEDULED PHASE INSPECTION PROGRAM	<ul style="list-style-type: none"> Deleted section. Inspection program definitions and information can be found in Chapter 5-00-00, 001- Time Limits/Maintenance Checks.

5-21-01	INSPECTION PHASE 1	<ul style="list-style-type: none"> • Added section for inspection program update. • Moved data from 05-21-01, 601. • Added to the Inspection Program: <ul style="list-style-type: none"> • Access Door Inspections (52-40-00-2100, 52-40-00-2101, 52-40-00-2102, and 52-40-00-2103). • Cabin Air Filter Cleaning (21-51-01-1600) • Aileron (Left and Right) Inspection (27-00-00-7104). • Added to this Phase: <ul style="list-style-type: none"> • Refrigerant Lines and Service Valves (21-50-01-2101). • Refrigerant Lines, Service Valves and High Pressure Valves (21-51-01-2100) • Condenser Blower (21-20-01-2110 and 21-51-01-2109) • Electric Elevator Trim Tab Free Play Functional Check (27-30-07-7201). • Engine Indication Reversion Functional Check (77-40-05-7200). • Lubrication Inspections for this interval from Chapter 12-20-11, 301 - Lubrication Schedule. • Combined Tasks: <ul style="list-style-type: none"> • REAR FUSELAGE DRAINS and VENTRAL FIN DRAIN HOLES (53-10-01-2100). • Removed from this Phase: <ul style="list-style-type: none"> • NOSE SECTION Inspection. • AVIONICS EQUIPMENT and RACKS and AVIONIC COMPARTMENT Inspections. Requirements were combined and added to Phase 2. • FIRE EXTINGUISHER (PORTABLE - Flight Compartment) Inspection • DEICER BOOTS (Rear Fuselage and Empennage) Inspection • MAIN LANDING GEAR ACTUATOR Inspection • MAIN LANDING GEAR DRAG BRACE Inspection • MAIN LANDING GEAR AREA Inspection • Split Tasks. <ul style="list-style-type: none"> • AUTOPILOT SERVO and CABLE (Rear Fuselage and Empennage) (22-13-11-2200, 22-13-15-2200, and 22-13-17-2200). • VERTICAL STABILIZER and HORIZONTAL STABILIZER (55-10-01-2800 and 55-30-01-2100). • FLAPS AND ACTUATORS (27-00-00-2108 and 27-50-11-7200) • ENGINE FIRE EXTINGUISHER (26-20-05-2100 and 26-20-05-7200). • PROPELLERS (61-10-01-2100 and 61-10-01-2104).
05-21-01	SCHEDULED INSPECTION PROGRAM (PHASE 1)	<ul style="list-style-type: none"> • Moved information to 5-21-01, 001. • Deleted empty section.

5-21-02	INSPECTION PHASE 2	<ul style="list-style-type: none"> • Added section for inspection program update. • Moved data from 05-21-02, 601. • Added to the Inspection Program: <ul style="list-style-type: none"> • Access Door Inspections (52-40-00-2100, 52-40-00-2101, 52-40-00-2102, and 52-40-00-2103). • Removed from the Inspection Program: <ul style="list-style-type: none"> • AFT COWLING ACCESS DOOR • Added to this Phase: <ul style="list-style-type: none"> • Cockpit Side Windows (56-00-00-2100) • Windshields (56-10-01-2100). • Lubrication Inspections for this interval from Chapter 12-20-11, 301 - Lubrication Schedule. • Combined Tasks: <ul style="list-style-type: none"> • AVIONICS EQUIPMENT and RACKS and AVIONICS COMPARTMENT (Nose and Avionics Bay Area). (53-00-00-2101). Moved from Phase 1. • Split Tasks. <ul style="list-style-type: none"> • FIRE DETECTION SYSTEM (26-10-00-2100 and 26-10-00-7200) • FUEL PURGE SYSTEM (71-70-01-1600, 71-70-00-1600, 71-70-00-1600 and 71-70-00-7200). • AIR-CONDITIONING COMPRESSOR (21-50-01-2108, 21-51-01-2107, 21-50-01-2111, and 21-51-01-2110). • Removed from this Phase: <ul style="list-style-type: none"> • LANDING and TAXI LIGHTS • LANDING GEAR STRUTS • ENGINE TRUSS BOLT TORQUE CHECK. Inspection Requirement Moved to Phase 44.
05-21-02	SCHEDULED INSPECTION PROGRAM (PHASE 2)	<ul style="list-style-type: none"> • Moved inspection data to 5-21-02, 001: Inspection Phase 2. • Deleted empty section.

5-21-03	INSPECTION PHASE 3	<ul style="list-style-type: none"> • Added section for inspection program update. • Moved data from 05-21-03, 601. • Added to the Inspection Program: <ul style="list-style-type: none"> • Access Doors Inspections (52-40-00-2100, 52-40-00-2101, 52-40-00-2102, and 52-40-00-2103) • Cabin Air Filter Cleaning(21-51-01-1600) • Cabin Entrance Door (52-40-01-7100) • Passenger Seats Operational Check (25-20-01-7101 and 25-21-01-7100) • Passenger Seat Belt and Shoulder Harness Operational Check (25-20-01-7101 and 25-21-01-7101) • Oxygen System Manual Operation Check (35-00-00-7202). • Added to this Phase: <ul style="list-style-type: none"> • Electrical Wiring and Equipment (Nose and Avionics Bay) (53-00-00-2109) from Phase 4 • Avionics and Autopilot Equipment and Racks (Rear Fuselage and Empennage) (53-00-00-2107) from Phase 4 • Electrical Wiring and Equipment for Rear Fuselage and Empennage (53-00-00-2112) from Phase 4 • Rear Fuselage and Empennage (53-00-00-2114). • Engine Indication Reversion Functional Check (77-40-05-7200). • Lubrication Inspections for this interval from Chapter 12-20-11, 301 - Lubrication Schedule. • Removed from this Phase: <ul style="list-style-type: none"> • FLIGHT CONTROLS COMPONENTS, CABLES and PULLEYS (Flight Compartment). Moved to Phase 13. • ENVIRONMENTAL SYSTEM (Flight Compartment). Moved to Phase 13. • FLIGHT CONTROL COMPONENTS, CABLES, and PULLEYS (Cabin). Moved to Phase 13. • WINDOW DEFOG SYSTEM. Moved to Phase 13. • CABIN AREA STRUCTURE. Moved to Phase 13. • ELECTRICAL WIRING and EQUIPMENT (Cabin). Moved to Phase 13. • ENVIRONMENTAL SYSTEM (Cabin). Moved to Phase 13. • PRESSURIZATION DUCTS. Moved to Phase 13. • MAIN LANDING GEAR ACTUATOR • MAIN LANDING GEAR DRAG BRACE • MAIN LANDING GEAR AREA
---------	--------------------	--

5-21-03	INSPECTION PHASE 3 (CONT'D)	<ul style="list-style-type: none"> • Split Tasks: <ul style="list-style-type: none"> • WINDSHIELDS (56-10-01-2100 and 56-10-01-2200). • RUDDER PEDALS (27-20-09-2100 and 27-20-09-2200). • CONTROL COLUMN (27-00-00-2106, 27-00-00-7100, and 27-10-05-2200). • ENGINE CONTROL LEVERS (76-10-09-2100 and 76-10-09-2200). • BUS CONFORMITY CHECK (24-50-00-7200 and 24-60-00-7200). • OUTFLOW and SAFETY VALVES (21-30-03-1600, 21-30-03-2200, 21-30-03-7200, and 21-30-00-7200). • CABIN ENTRANCE DOOR (FL) (52-10-01-2200 and 52-10-01-7100). • CABIN CARGO DOOR and CABIN ENTRANCE DOOR (FM) (52-30-00-2100, 52-30-00-2200, and 52-30-00-7100). • AUTOPILOT SERVOS and CABLES (Rear Fuselage and Empennage) (22-13-11-2200, 22-13-15-2200, and 22-13-17-2200). • FLAPS and ACTUATORS (27-00-00-2108 and 27-50-11-7200). • ENGINE FIRE EXTINGUISHER (26-20-05-2100 and 26-20-05-7200). • PROPELLERS (61-10-01-2100 and 61-10-01-2104). • Combined tasks: <ul style="list-style-type: none"> • CABIN DOOR and EMERGENCY EXITS and EMERGENCY EXITS (52-20-01-2200) • REAR FUSELAGE DRAINS and VENTRAL FIN DRAIN HOLES (53-10-01-2100).
05-21-03	SCHEDULED INSPECTION PROGRAM (PHASE 3)	<ul style="list-style-type: none"> • Moved inspection data to 5-21-03, 001: Inspection Phase 3. • Deleted empty section.

5-21-04	INSPECTION PHASE 4	<ul style="list-style-type: none"> • Added section for inspection program update. • Moved data from 05-21-04, 601. • Added to the Inspection Program: <ul style="list-style-type: none"> • Access Doors Inspections (52-40-00-2100, 52-40-00-2101, 52-40-00-2102, and 52-40-00-2103) • Removed from the Inspection Program: <ul style="list-style-type: none"> • INSTRUMENT AIR FILTER • AFT COWLING ACCESS DOOR • Added to this Phase: <ul style="list-style-type: none"> • Lubrication Inspections for this interval from Chapter 12-20-11, 301 - Lubrication Schedule. • Removed from this Phase: <ul style="list-style-type: none"> • ELECTRICAL WIRING and EQUIPMENT (Nose and Avionics Bay). Moved to Phase 3. • PRESSURIZATION DUCTS (Cabin). Moved to Phase 13. • FLAPPER VALVE. Moved to Phase 3. • NAVIGATION LIGHTS and UPPER BEACON LIGHT • ELECTRICAL WIRING and EQUIPMENT (Rear Fuselage and Empennage). Moved to Phase 3. • AVIONICS and AUTOPILOT EQUIPMENT and RACKS (Rear Fuselage and Empennage). Moved to Phase 3. • FLIGHT CONTROL COMPONENTS, CABLES and PULLEYS (Rear Fuselage and Empennage). • CONTROL CABLE SEALS (Rear Fuselage and Empennage). • STATIC GROUND RECEPTACLES • DEICER BOOTS • Split Tasks: <ul style="list-style-type: none"> • AUTOPILOT SERVOS and CABLES (Rear Fuselage and Empennage) (22-13-11-2200, 22-13-15-2200, and 22-13-17-2200). • AIR CONDITIONING COMPRESSOR (21-50-01-2108, 21-51-01-2107, 21-50-01-2111, and 21-51-01-2110), • FUEL PURGE SYSTEM (71-70-01-1600, 71-70-03-1600, 71-70-00-1600, and 71-70-00-7200). • DOORS and LINKAGE (32-10-03-2210 and 32-20-03-2211). • Combined: <ul style="list-style-type: none"> • AVIONICS EQUIPMENT and RACKS and AVIONICS COMPARTMENT (Nose and Avionics Bay) (53-00-00-2101) • REAR FUSELAGE DRAINS and VENTRAL FIN DRAIN HOLES (53-10-01-2100).
05-21-04	SCHEDULED INSPECTION PROGRAM (PHASE 4)	<ul style="list-style-type: none"> • Moved inspection data to 5-21-04, 001: Inspection Phase 4. • Deleted empty section.

5-21-05	INSPECTION PHASE 5	<ul style="list-style-type: none"> Added Inspection Phase 5 for the first dual inspection interval (Phase 1 and 2 Combined). Added Phase 1 and Phase 2 tasks without duplicates.
05-21-05	SCHEDULED INSPECTION PROGRAM (PHASE 5)	<ul style="list-style-type: none"> Moved inspection data to Inspection Phase 8 thru Phase 52 for inspection program update. Deleted empty section.
5-21-06	INSPECTION PHASE 6	<ul style="list-style-type: none"> Added Inspection Phase 6 for the second dual inspection interval (Phase 3 and Phase 4 combined). Added Phase 3 and Phase 4 tasks without duplicates.
5-21-08	INSPECTION PHASE 8	<ul style="list-style-type: none"> Added Inspection Phase 8 for 12-month interval inspection items. Added the ELT Operational Check requirement to this inspection detail (Task 25-60-00-7100).
5-21-09	INSPECTION PHASE 9	<ul style="list-style-type: none"> Added Inspection Phase 9 for special inspections to be completed every 1200 hours.
5-21-10	INSPECTION PHASE 10	<ul style="list-style-type: none"> Added Inspection Phase 10 for special inspection items at intervals of 1000 cycles.
5-21-11	INSPECTION PHASE 11	<ul style="list-style-type: none"> Added Inspection Phase 11 for special inspection items at 2400 hours or 30 months, whichever occurs first.
5-21-12	INSPECTION PHASE 12	<ul style="list-style-type: none"> Added Inspection Phase 12 for special inspection items at 24 months.
5-21-13	INSPECTION PHASE 13	<ul style="list-style-type: none"> Added Inspection Phase 13 for special inspection items at 2500 cycles. Added to this Phase: <ul style="list-style-type: none"> Pressurization Ducts (21-30-00-2100) Environmental System (Flight Compartment) (21-51-01-2104 and 21-50-01-2105) Environmental System (Cabin) (21-51-01-2105 and 21-50-01-2107). Flight Control Components, Cables, and Pulleys (Flight Compartment) (27-00-00-2100) Flight Control Components, Cables, and Pulleys (Cabin) (27-00-00-2101) Window Defog System (30-40-13-2100). Cabin Area Structure (53-00-00-2104) Electrical Wiring and Equipment (Cabin) (53-00-00-2111).
5-21-14	INSPECTION PHASE 14	<ul style="list-style-type: none"> Added Inspection Phase 14 for special inspection items at 3000 cycles.
5-21-15	INSPECTION PHASE 15	<ul style="list-style-type: none"> Added Inspection Phase 15 for King Air SIRM inspections that occur at the Chapter 57-18-02, Table 201 interval defined by items (9), (12), and (13).
5-21-16	INSPECTION PHASE 16	<ul style="list-style-type: none"> Added Inspection Phase 16 for special inspections at 5000 cycles.

5-21-17	INSPECTION PHASE 17	<ul style="list-style-type: none"> Added Inspection Phase 17 for special inspections at 5000 hours.
5-21-18	INSPECTION PHASE 18	<ul style="list-style-type: none"> Added Inspection Phase 18 for special inspection items at 5000 cycles then every 1000 cycles interval.
5-21-19	INSPECTION PHASE 19	<ul style="list-style-type: none"> Added Inspection Phase 19 for special inspection for every 8000 cycles or 36 months, whichever occurs first.
5-21-20	INSPECTION PHASE 20	<ul style="list-style-type: none"> Added Inspection Phase 20 for special inspections at 8000 cycles or 72 months, whichever occurs first.
5-21-21	INSPECTION PHASE 21	<ul style="list-style-type: none"> Added Inspection Phase 21 for special inspection items at 10,000 cycles.
5-21-22	INSPECTION PHASE 22	<ul style="list-style-type: none"> Added Inspection Phase 22 for special inspections to be completed every 10,000 cycles, then every 500 cycles thereafter.
5-21-23	INSPECTION PHASE 23	<ul style="list-style-type: none"> Added Inspection Phase 23 for special inspection at the 10,000 cycles, then every 1000 cycles thereafter
5-21-24	INSPECTION PHASE 24	<ul style="list-style-type: none"> Added Inspection Phase 24 for special inspection items at 10,000 cycles, then every 5000 cycles thereafter.
5-21-25	INSPECTION PHASE 25	<ul style="list-style-type: none"> Added Inspection Phase 25 for special inspection items to be completed at the first 200 hours on a new airplane or after a new cable installation or rigging break, then every 48 months thereafter. Added to this Phase: <ul style="list-style-type: none"> Flight Control Components, Cables, and Pulleys (Cabin) (27-00-00-2101)
5-21-26	INSPECTION PHASE 26	<ul style="list-style-type: none"> Added Inspection Phase 26 for special inspection items at 200 hours (new airplanes only).
5-21-27	INSPECTION PHASE 27	<ul style="list-style-type: none"> Added Inspection Phase 27 for special inspection items to be completed every 12,000 hours.
5-21-28	INSPECTION PHASE 28	<ul style="list-style-type: none"> Added Inspection Phase 28 for special inspection items at 100 hours on a new or overhauled engine.
5-21-29	INSPECTION PHASE 29	<ul style="list-style-type: none"> Added Inspection Phase 29 for special inspection items to be completed at 200 hours, then every 1200 hours thereafter, or any time a system is contaminated.
5-21-30	INSPECTION PHASE 30	<ul style="list-style-type: none"> Added Inspection Phase 30 for special inspection items at the first 200 hours, then every 5000 hours thereafter.
5-21-31	INSPECTION PHASE 31	<ul style="list-style-type: none"> Added Inspection Phase 31 for special inspection items at the first 600 hours, then every 18 months thereafter.
5-21-32	INSPECTION PHASE 32	<ul style="list-style-type: none"> Added Inspection Phase 32 for special inspection items to be completed every 2500 cycles until 10,000 cycles, then every 1000 cycles thereafter.

5-21-33	INSPECTION PHASE 33	<ul style="list-style-type: none"> Added Inspection Phase 33 for special inspections to be completed 60 months after being placed in service, but no longer than 63 months after the date of manufacture.
5-21-34	INSPECTION PHASE 34	<ul style="list-style-type: none"> Added Inspection Phase 34 for special inspection items to be completed at the first 72 months, then every 12 months thereafter.
5-21-35	INSPECTION PHASE 35	<ul style="list-style-type: none"> Added Inspection Phase 35 for special inspections to be completed 120 months from the date of manufacture.
5-21-36	INSPECTION PHASE 36	<ul style="list-style-type: none"> Added Inspection Phase 36 for special inspection items to be completed in accordance with the applicable vendor manual.
5-21-37	INSPECTION PHASE 37	<ul style="list-style-type: none"> Added Inspection Phase 37 for special inspection items to be completed in accordance with the crew oxygen mask manufacturer's component maintenance manual.
5-21-38	INSPECTION PHASE 38	<ul style="list-style-type: none"> Added Inspection Phase 38 for special inspection items to be completed in accordance with the landing gear wheel manufacturer's component maintenance manual..
5-21-39	INSPECTION PHASE 39	<ul style="list-style-type: none"> Added Inspection Phase 39 for King Air SIRM inspections that occur at the Chapter 57-18-02, Table 201 interval defined by item (4).
5-21-40	INSPECTION PHASE 40	<ul style="list-style-type: none"> Added Inspection Phase 40 for special inspection items to be completed in accordance with P&W SB 13303.
5-21-41	INSPECTION PHASE 41	<ul style="list-style-type: none"> Added Inspection Phase 41 for special inspection items to be completed in accordance with 174095-SIL-1 or subsequent.
5-21-42	INSPECTION PHASE 42	<ul style="list-style-type: none"> Added Inspection Phase 42 for special inspection items to be completed at the next scheduled inspection after wing installation, then every 12 months thereafter.
5-21-43	INSPECTION PHASE 43	<ul style="list-style-type: none"> Added Inspection Phase 43 for special inspection items to be completed at 800 hours or 24 months, whichever occurs first.
5-21-44	INSPECTION PHASE 44	<ul style="list-style-type: none"> Added Inspection Phase 44 for new inspection interval to be completed at the first 200 hours after installation. Added Engine Truss Bolt Check from Phase 2.
5-21-45	INSPECTION PHASE 45	<ul style="list-style-type: none"> Added Inspection Phase 45 for lubrication inspection items to be completed every 6500 hours or 48 months, whichever occurs first, or after removal and installation.
5-21-46	INSPECTION PHASE 46	<ul style="list-style-type: none"> Added Inspection Phase 46 for special inspection items to be completed every 2000 hours or 48 months, whichever occurs first.

5-21-47	INSPECTION PHASE 47	<ul style="list-style-type: none"> Added Inspection Phase 47 for King Air Structural Inspection and Repair Manual inspections that occur at the Chapter 57-18-02, Table 201 interval defined by Index Items (5), (6), and (7).
5-21-48	INSPECTION PHASE 48	<ul style="list-style-type: none"> Added Inspection Phase 48 for King Air SIRM inspections that occur at the Chapter 57-18-02, Table 201 interval defined by item (2).
5-21-49	INSPECTION PHASE 49	<ul style="list-style-type: none"> Added Inspection Phase 49 for King Air SIRM inspections that occur at the Chapter 57-18-02, Table 201 interval defined by item (1).
5-21-50	INSPECTION PHASE 50	<ul style="list-style-type: none"> Added Inspection Phase 50 for King Air SIRM inspections that occur at the Chapter 57-18-02, Table 201 interval defined by items (3) and (14).
5-21-51	INSPECTION PHASE 51	<ul style="list-style-type: none"> Added Inspection Phase 51 for King Air SIRM inspections that occur at the Chapter 57-18-02, Table 201 interval defined by item (11).
5-21-52	INSPECTION PHASE 52	<ul style="list-style-type: none"> Added Inspection Phase 52 for King Air SIRM inspections that occur at the Chapter 57-18-02, Table 201 interval defined by item (8).
5-21-53	INSPECTION PHASE 53	<ul style="list-style-type: none"> Added Inspection Phase 53 for special inspection items to be completed at the first 2500 cycles, then every 500 cycles thereafter.
5-21-54	INSPECTION PHASE 54	<ul style="list-style-type: none"> Added Inspection Phase 54 for special inspection items to be completed at the first 10,000 cycles, then every 2500 cycles thereafter.
05-22-00	BIENNIAL INSPECTION PROGRAM	<ul style="list-style-type: none"> Updated front matter to align with new inspection program. Reorganized section for flow.

<p>5-22-01</p>	<p>BIENNIAL SCHEDULED INSPECTION PROGRAM (INTERIM)</p>	<ul style="list-style-type: none"> • Added section for inspection program update. • Moved data from 5-22-01, 601. • Removed Operational Checks from Interim: <ul style="list-style-type: none"> • STANDBY PUMPS • STARTER • VACUUM SYSTEM INSTRUMENT • RUDDER BOOST • ELECTRICAL SYSTEM • STALL WARNING • GENERATORS • CONDITION LEVERS • COCKPIT LIGHTS • ELECTRIC ELEVATOR TRIM • WINDSHIELDS • THRESHOLD LIGHT • CABIN and COMPARTMENT LIGHTS • WING CENTER SECTION LIGHTS • Added to Interim: <ul style="list-style-type: none"> • Engine Periodic Inspections (71-00-01-2200) • Combined Tasks: <ul style="list-style-type: none"> • Ignition and Autoignition (74-10-03-7100) • Propellers, Propeller Governor, and Idle RPM (76-10-15-7100) • Split Tasks: <ul style="list-style-type: none"> • Engine Oil Temperature and Engine Oil Pressure (77-40-17-7100 and 77-40-19-7100) • Environmental System (21-40-01-7100, 21-41-07-7100, 21-50-01-7200, and 21-51-01-7200)
<p>05-22-01</p>	<p>BIENNIAL SCHEDULED INSPECTION PROGRAM (INTERIM)</p>	<ul style="list-style-type: none"> • Moved data to 05-22-01, 001 per inspection program reorganization. • Deleted empty section.

<p>5-22-02</p>	<p>BIENNIAL SCHEDULED INSPECTION PROGRAM (COMPLETE)</p>	<ul style="list-style-type: none"> • Added section for inspection program update. • Moved data from 5-22-02, 601. • Removed from the Inspection Program: <ul style="list-style-type: none"> • INSTRUMENT AIR FILTER • AFT COWLING ACCESS DOOR • Added to the Inspection Program: <ul style="list-style-type: none"> • Cabin Air Filter Cleaning(21-51-01-1600) • Oxygen System Manual Operation Check (35-00-00-7202). • Added to the Biennial Complete: <ul style="list-style-type: none"> • Air Conditioning Condenser (21-50-01-2109 and 21-51-01-2108). • Engine Control Levers Condition Control Catch Gate (76-10-09-2100) • Refrigerant Lines and Pressure Switches (Wing) (21-50-01-2103 and 21-51-01-2102) • Main Lower Spar Cap Bumper Block (57-00-00-2200) • Engine Periodic Inspections (71-00-01-2200) • Lubrication Inspections for this interval from Chapter 12-20-11, 301 - Lubrication Schedule. • Removed from Biennial Complete: <ul style="list-style-type: none"> • NOSE LANDING GEAR DRAG BRACE STOP LUGS • ALL COMPONENTS (Nose Landing Gear) • FLIGHT CONTROL COMPONENTS, CABLES, and PULLEYS. Moved to Phase 13. • ENVIRONMENTAL SYSTEM. Moved to Phase 13. • PRESSURIZATION DUCTS. Moved to Phase 13. • WINDOW DEFOG SYSTEM. Moved to Phase 13. • ELECTRICAL WIRING and EQUIPMENT (Cabin). Moved to Phase 13. • HYDRAULIC LINES, LANDING GEAR • SPARK IGNITER PLUGS • P3 AIR FILTER • Removed Operational Checks from Complete: <ul style="list-style-type: none"> • STANDBY PUMPS • STARTER • VACUUM SYSTEM INSTRUMENT • RUDDER BOOST • ELECTRICAL SYSTEM • STALL WARNING • GENERATORS • CONDITION LEVERS • COCKPIT LIGHTS • ELECTRIC ELEVATOR TRIM • WINDSHIELDS • THRESHOLD LIGHT • CABIN and COMPARTMENT LIGHTS • WING CENTER SECTION LIGHTS
----------------	---	--

<p>5-22-02</p>	<p>BIENNIAL SCHEDULED INSPECTION PROGRAM (COMPLETE) (CONTD)</p>	<ul style="list-style-type: none"> • Combined Tasks: <ul style="list-style-type: none"> • Avionics Compartment, Equipment and Racks (Nose and Avionics Bay) (53-00-00-2101) • Instances of Left and Right Aircraft Areas (ex: Left Wing and Right Wing are now just Wing). • Cabin Door and Emergency Exits and Emergency Exits (52-20-01-2200) • Ignition and Autoignition (74-10-03-7100) • Propellers, Propeller Governor, and Idle RPM (76-10-15-7100) • Split Tasks: <ul style="list-style-type: none"> • Landing and Taxi Light (33-40-00-6100 and 33-40-00-2102) • Control Column (27-00-00-2106, 27-00-00-7100, and 27-10-05-2200). • Bus Conformity Check (24-50-00-7200 and 24-60-00-7200). • Outflow and Safety Valves (21-30-03-1600, 21-30-03-2200, 21-30-03-7200, and 21-30-00-7200). • Rear Fuselage Drains and Ventral Fin Drain Holes (53-10-01-2100). • Empennage and Control Surfaces (27-30-07-7200, 27-20-11-7200, and 27-20-19-7200). • Autopilot Servo and Cables (Rear Fuselage and Empennage) (22-13-11-2200, 22-13-15-2200, and 22-13-17-2200). • Flaps and Actuators (27-00-00-2108 and 27-50-11-7200). • Engine Fire Extinguisher (26-20-05-2100 and 26-20-05-7200). • Fuel Purge System (71-70-01-1600, 71-70-03-1600, 71-70-00-1600, and 71-70-00-7200). • Engine Oil Temperature and Engine Oil Pressure (77-40-17-7100 and 77-40-19-7100) • Doors and Linkage (32-10-03-2210 and 32-20-03-2211). • Environmental System (21-40-01-7100, 21-41-07-7100, 21-50-01-7200, and 21-51-01-7200)
<p>05-22-02</p>	<p>BIENNIAL SCHEDULED INSPECTION PROGRAM (COMPLETE)</p>	<ul style="list-style-type: none"> • Moved data to 05-22-02, 001 per inspection program reorganization. • Deleted empty section.

5-23-00	CONTINUOUS CORROSION CONTROL INSPECTION	<ul style="list-style-type: none"> Moved data from 5-23-00, 601 to this section. Combined skin, access panels, winglet, fuel vents and drains, fuel filler caps, and deicer boots inspections from Tables 601 and 602 into Task 57-00-00-2105. Combined flap and aileron cove area, aileron and tab, outboard flaps, inboard flaps, flap tracks, and flap actuator inspections from Tables 601 and 602 into Task 57-00-00-2803. Combined skin, access doors, antennas, drain hoses/holes, static ports, relief tube, deicer boots, radome, doors, and fairings inspections from Table 603, 604, 612, and 613 into Task 53-00-00-2116.
05-23-00	CONTINUOUS CORROSION CONTROL INSPECTION	<ul style="list-style-type: none"> Moved data to 05-23-00, 001. Deleted empty section.
5-50-00	UNSCHEDULED MAINTENANCE CHECKS	<ul style="list-style-type: none"> Moved information from 05-50-00, 601 for Chapter 5 reorganization. No technical data changes were made.
05-50-00	UNSCHEDULED MAINTENANCE CHECKS	<ul style="list-style-type: none"> Moved data to 05-50-00, 001 per inspection program reorganization. Deleted empty section.
Chapter 07	LIST OF EFFECTIVE PAGES	
Chapter 07	TABLE OF CONTENTS	
07-10-01	HOISTING - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
07-10-05	THREE POINT JACKING - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 08	LIST OF EFFECTIVE PAGES	
Chapter 08	TABLE OF CONTENTS	
08-20-00	LEVELING - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected broken hyperlinks Fixed missing revision bar.
Chapter 09	LIST OF EFFECTIVE PAGES	
Chapter 09	TABLE OF CONTENTS	
09-10-00	TOWING - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 10	LIST OF EFFECTIVE PAGES	
Chapter 10	TABLE OF CONTENTS	
10-10-01	CONTROL LOCKS - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
10-20-00	MOORING - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 12	LIST OF EFFECTIVE PAGES	
Chapter 12	TABLE OF CONTENTS	

12-10-05	LANDING GEAR SYSTEM - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
12-10-07	CABIN ENTRANCE DOOR DAMPER - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
12-10-11	AIR CONDITIONING SYSTEM - SERVICING	<ul style="list-style-type: none"> Added procedures and illustrations for R12 refrigerant airplanes. Added breakdowns for processes between airplane models. Revised Air Quality Control Warning to add R-12 refrigerant. Added high pressure system warning.
12-10-13	OXYGEN SYSTEM - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
12-20-01	ENGINE WASHING - SERVICING	<ul style="list-style-type: none"> Updated Engine motoring time.
12-20-03	CLEANING AIRPLANE EXTERIORS - SERVICING	<ul style="list-style-type: none"> Revised entire section to incorporate Corrosion Prevention and Control Program considerations. Revised section for inspection program update. Added tables for materials and schedules
12-20-05	ENGINE INERTIAL ANTHICING SYSTEM - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
12-20-09	TOILET - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
12-20-11	LUBRICATION SCHEDULE - SERVICING	<ul style="list-style-type: none"> Added FM serials to Section J and segregated FL and FM serials between the 130-3004-1 and -3 kits. Added NYCO GN 3058 grease to Tables 301 and Table under Item L. Added the aft upper and aft lower wing bolt lubrication in Table under Item I. Wings. Removed most of the lubrication intervals and replaced them with a note stating the lubrications are now part of the scheduled inspection program.
12-30-09	DEICING - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
12-30-11	ANTHCING - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
12-30-17	RESIDUE FROM DEICE/ANTHCE FLUIDS - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 21	LIST OF EFFECTIVE PAGES	
Chapter 21	TABLE OF CONTENTS	
21-10-00	PRESSURIZATION - TROUBLESHOOTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-10-03	AMBIENT-AIR TEMPERATURE SENSOR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

21-10-05	FLOW CONTROL VALVE - DESCRIPTION AND OPERATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-10-05	FLOW CONTROL VALVE - TROUBLESHOOTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-10-05	FLOW CONTROL VALVE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-10-05	FLOW CONTROL VALVE - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 21-10-05-2100.
21-10-07	ELECTRONIC CONTROLLER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-10-09	BLEED AIR FLOW RATE - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-10-11	BLEED AIR FLOW RATE - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-20-09	CHECK (FLAPPER) VALVE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-20-09	CHECK (FLAPPER) VALVE - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-20-11	ENVIRONMENTAL BLEED AIR DUCTS - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-30-00	PRESSURIZATION CONTROL - DESCRIPTION AND OPERATION	<ul style="list-style-type: none"> Revised pressurization terminology to be consistent throughout the document. Updated and revised illustration for accuracy,
21-30-00	PRESSURIZATION CONTROL - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 21-30-00-2100, 21-30-00-2101, 21-30-00-2200, 21-30-00-7100, 21-30-00-7101 and 21-30-00-7200.
21-30-01	PRESSURIZATION CONTROLLER FILTER - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-30-03	OUTFLOW VALVE AND SAFETY VALVE - SERVICING	<ul style="list-style-type: none"> Updated outflow and safety valve graphics.
21-30-03	OUTFLOW VALVE AND SAFETY VALVE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Revised pressurization graphics and added NOTE to mark lines before disconnecting.
21-30-03	OUTFLOW VALVE AND SAFETY VALVE - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 21-30-03-1600, 21-30-03-2200, and 21-30-03-7200
21-30-03	OUTFLOW VALVE AND SAFETY VALVE - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-30-11	CABIN ALTITUDE HIGH WARNING PRESSURE SWITCH - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Revised Chapter 5 references under Step 1.

21-30-11	CABIN ALTITUDE HIGH WARNING PRESSURE SWITCH - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 21-30-11-7200.
21-40-01	BLEED AIR BYPASS VALVE - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added task 21-40-01-7100.
21-40-03	BLEED AIR BYPASS MICROSWITCH - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-40-11	AFT ELECTRIC HEAT EQUIPMENT PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-40-13	FORWARD ELECTRIC HEAT EQUIPMENT PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-41-00	HEATING - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 21-41-00-7200.
21-41-07	BLEED AIR BYPASS VALVE - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 21-41-07-7100 and task format to existing procedure.
21-41-09	AFT ELECTRIC HEAT EQUIPMENT PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-41-11	FORWARD ELECTRIC HEAT EQUIPMENT PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-50-00	COOLING - SERVICING - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-50-00	COOLING - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 21-50-00-2100.
21-50-01	AIR CONDITIONING SYSTEM - SERVICING	<ul style="list-style-type: none"> Rewrote section to add information for pre-Keith systems. Expanded the section tools, equipment and materials. Added procedures and warnings. Revised high pressure system warning for clarification.
21-50-01	AIR CONDITIONING SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for the inspection program update. Added Tasks 21-50-04-2100, 21-50-01-2101, 21-50-01-2102, 21-50-01-2103, 21-50-01-2104, 21-50-01-2105, 21-50-01-2106, 21-50-01-2107, 21-50-01-2108, 21-50-01-2109, 21-50-01-2110, 21-50-01-2111, 21-50-01-6400, 21-50-01-7200, and 21-50-01-9600
21-50-01	AIR CONDITIONING SYSTEM - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-50-07	COMPRESSOR - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-50-07	COMPRESSOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

21-50-09	COMPRESSOR BELT - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-50-09	COMPRESSOR BELT - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-50-11	COMPRESSOR MOUNT - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-50-21	FORWARD EVAPORATOR FILTER - SERVICING	<ul style="list-style-type: none"> New section for servicing of the forward evaporator filter.
21-50-23	AFT EVAPORATOR FILTER - SERVICING	<ul style="list-style-type: none"> New section for aft evaporator filter servicing.
21-51-01	AIR CONDITIONING SYSTEM - SERVICING	<ul style="list-style-type: none"> Updated Union part number to BS6009-6 in Step H, 20.
21-51-01	AIR CONDITIONING SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 21-51-01-1600, 21-51-01-2100, 21-51-01-2101, 21-51-01-2102, 21-51-01-2103, 21-51-01-2104, 21-51-01-2105, 21-51-01-2106, 21-51-01-2107, 21-51-01-2108, 21-51-01-2109, 21-51-01-2110, and 21-51-01-6400.
21-51-03	COMPRESSOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-51-05	COMPRESSOR BELT - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-51-05	COMPRESSOR BELT - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-51-07	COMPRESSOR MOUNT - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-51-11	CONDENSER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-51-17	RECEMER/DRYER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-51-19	COCKPIT EVAPORATOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-51-21	COCKPIT EVAPORATOR BLOWER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-51-23	COCKPIT AND CABIN EXPANSION VALVE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-51-25	CABIN EVAPORATOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-51-25	CABIN EVAPORATOR - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-51-27	CABIN EVAPORATOR BLOWER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

21-51-29	PRESSURE SWITCH - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-60-00	TEMPERATURE CONTROL - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Reformatted existing inspection into Task 21-60-00-7200.
21-60-03	CABIN TEMPERATURE INDICATOR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-60-05	CABIN TEMPERATURE CONTROLLER - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
21-61-00	TEMPERATURE CONTROL - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Reformatted existing inspection into Task 21-61-00-7200.
Chapter 22	LIST OF EFFECTIVE PAGES	
Chapter 22	TABLE OF CONTENTS	
22-10-00	APS-65 AUTOMATIC FLIGHT CONTROL SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 22-10-00-2100, 22-10-00-2200 and 22-10-00-7100
22-13-07	AILERON SERVO AND MOUNT - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Added the Pro Line 21 Manual reference.
22-13-07	AILERON SERVO AND MOUNT - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Updated manual reference
22-13-07	AILERON SERVO AND MOUNT - INSPECTION/CHECK	<ul style="list-style-type: none"> Added the section for inspection program update. Added Task 22-13-07-2200.
22-13-11	RUDDER SERVO AND MOUNT - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 22-13-11-2200 and 22-13-11-6400.
22-13-15	ELEVATOR SERVO AND MOUNT - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 22-13-15-2200.
22-13-17	ELEVATOR TRIM TAB SERVO AND MOUNT - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected broken hyperlinks.
22-13-17	ELEVATOR TRIM TAB SERVO AND MOUNT - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for the inspection program update. Added Task 22-13-17-2200.
22-13-19	SERVO MOUNT SLIP CLUTCH (SMT-65 AND SMT-85B) - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Revised Chapter 5 references in accordance with inspection program update.
22-13-19	SERVO MOUNT SLIP CLUTCH (SMT-65 AND SMT-85B) - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for the inspection program update. Added Task 22-13-19-2200.
22-13-23	DATA CONCENTRATOR UNIT - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 22-13-23-7100.
22-13-25	STALL WARNING - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 22-13-25-7100.
22-13-31	ELEVATOR TRIM TAB SERVO CABLE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 23	LIST OF EFFECTIVE PAGES	

Chapter 23	TABLE OF CONTENTS	
23-00-00	COMMUNICATIONS - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 23-00-00-2100.
23-10-07	COMM, NAV, ADF, TRANSPONDER, ETC. ANTENNA - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
23-11-01	RECEIVER/TRANSMITTER (HF-9031A) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
23-11-03	ANTENNA COUPLER (HF-9041) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
23-15-13	DUAL PATCH ANTENNA - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
23-31-01	PROGRAMMABLE SWITCH (PSW) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
23-31-03	SOLID STATE MINI SWITCH - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
23-51-00	AUDIO STORAGE AND PLAYBACK UNIT (ASPU) - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
23-60-00	STATIC DISCHARGERS (WICKS) - INSPECTION/CHECK	<ul style="list-style-type: none"> Updated section for inspection program update. Reformatted existing inspection into Task 23-60-00-2200. Added Tasks 23-60-00-2100 and 23-60-00-2101.
23-60-01	FLIGHT SURFACE AND WINGLET STATIC DISCHARGER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
23-70-00	COCKPIT VOICE RECORDER - DESCRIPTION AND OPERATION	<ul style="list-style-type: none"> Corrected Chapter 5 references in accordance with the inspection program update.
23-70-00	COCKPIT VOICE RECORDER - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 23-70-00-7100 and 23-70-00-9600.
Chapter 24	LIST OF EFFECTIVE PAGES	
Chapter 24	TABLE OF CONTENTS	
24-20-01	INVERTER SYSTEM - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-20-01	INVERTER SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Add Task 24-20-01-7100.
24-20-03	AC POWER DISTRIBUTION AND LIFT COMPUTER PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-20-05	CABIN FLUORESCENT LIGHTING POWER SUPPLY PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-30-00	DC GENERATION AND CONTROL SYSTEM - TROUBLESHOOTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

24-30-01	BATTERY - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-30-01	BATTERY - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added Tasks 24-30-01-2100 and 24-30-01-7200
24-30-03	STARTER/GENERATOR - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-30-03	STARTER/GENERATOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Updated Step B.(2) and Note in the Installation procedure.
24-30-03	STARTER/GENERATOR - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Reformatted existing inspection information into Task 24-30-03-2100. Added illustration to Task 24-30-03-2100. Added Task 24-30-03-9600.
24-30-05	GENERATOR CONTROL PANEL - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-30-07	GENERATOR CONTROL RELAY - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-30-09	LEADING EDGE ELECTRICAL EQUIPMENT PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-30-11	BATTERY POWER AND DISTRIBUTION EQUIPMENT PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-33-01	NICKEL-CADMIUM BATTERY - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-35-01	BATTERY MONITOR - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-40-00	EXTERNAL POWER - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 24-40-00-7100
24-40-01	EXTERNAL POWER RECEPTACLE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-50-00	ELECTRICAL LOAD DISTRIBUTION SYSTEM - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bars. No technical data changes were made.
24-50-00	ELECTRICAL LOAD DISTRIBUTION SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added task 24-50-00-7200.
24-50-03	INBOARD NACELLE POWER DISTRIBUTION ELECTRICAL PANELS - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
24-50-05	MAIN POWER DISTRIBUTION PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

24-60-00	DC ELECTRICAL LOAD DISTRIBUTION SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Reformatted existing inspection into Task 24-60-00-7200.
Chapter 25	LIST OF EFFECTIVE PAGES	
Chapter 25	TABLE OF CONTENTS	
25-10-00	PILOT AND COPILOT SEAT - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
25-10-00	PILOT AND COPILOT SEAT - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection update program. Added Tasks 25-10-00-2100 and 25-10-00-2101.
25-10-01	CARPET - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
25-10-03	UPHOLSTERY - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 25-10-03-2100
25-20-01	PASSENGER SEAT - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
25-20-01	PASSENGER SEAT - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
25-20-01	PASSENGER SEAT - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added Tasks 25-20-01-2100, 25-20-01-2101, 25-20-01-7100 and 25-20-01-7101.
25-20-13	CARPET - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
25-20-21	UPPER RIGHT VESTIBULE UPHOLSTERY PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
25-21-01	PASSENGER SEAT - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
25-21-01	PASSENGER SEAT - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
25-21-01	PASSENGER SEAT - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added Tasks 25-21-01-2100, 25-21-01-2101, 25-21-01-7100, and 25-21-01-7101.
25-21-39	CARPET - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Removed duplicate 'Removal/Installation' from title. Reformatted section effectivity.
25-60-00	EMERGENCY LOCATOR TRANSMITTER (ELT) - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 25-60-00-2200, 25-60-00-7100, and 25-60-00-9600.
25-60-09	EMERGENCY AND SURVIVAL EQUIPMENT - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 25-60-09-2100, 25-60-09-2101 and 25-60-09-2200.

25-80-01	MASS LOADED VINYL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
25-80-03	BETWEEN FRAME INSULATION BLANKET - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 26	LIST OF EFFECTIVE PAGES	
Chapter 26	TABLE OF CONTENTS	
26-10-00	DETECTION SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 26-10-00-2100, 26-10-00-7100 and 26-10-00-7200
26-20-00	FIRE EXTINGUISHING SYSTEM - DESCRIPTION AND OPERATION	<ul style="list-style-type: none"> Changed the description to 8 spray tubes and 4 in the accessory area.
26-20-00	FIRE EXTINGUISHING SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 26-20-00-7100.
26-20-03	FIRE EXTINGUISHER SUPPLY CYLINDER - SERVICING	<ul style="list-style-type: none"> Revised Chapter 5 hyperlinks in accordance with inspection program update. No technical data changes were made.
26-20-05	FIRE EXTINGUISHER ACTIVATION - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 26-20-05-2100 and 26-20-05-7200.
26-20-07	FIRE EXTINGUISHER SQUIB - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
26-21-00	PORTABLE FIRE EXTINGUISHER - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added Tasks 26-21-00-2100 and 26-21-00-2101.
Chapter 27	LIST OF EFFECTIVE PAGES	
Chapter 27	TABLE OF CONTENTS	
27-00-00	FLIGHT CONTROL SYSTEM - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-00-00	FLIGHT CONTROL SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Reformatted existing inspection information into Task 27-00-00-2200. Added General Visual Inspection tasks 27-00-00-2100, 27-00-00-2101, 27-00-00-2102, 27-00-00-2103, 27-00-00-2104, 27-00-00-2105, 27-00-00-2106, 27-00-00-2107, 27-00-00-2108, 27-00-00-2109, 27-00-00-2110, 27-00-00-2111, 27-00-00-2112, and 27-00-00-2113. Added Detailed Inspection Task 27-00-00-2201 Added Lubrication inspection tasks 27-00-00-6400, 27-00-00-6401, 27-00-00-6402, 27-00-00-6403, 27-00-00-6404, and 27-00-00-6405. Added Operational inspection tasks 27-00-00-7100, 27-00-00-7101, 27-00-00-7102, 27-00-00-7103, and 27-00-00-7104. Added Restoration inspection task 27-00-00-9600.

27-10-03	CONTROL COLUMN CABLE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-10-05	CONTROL COLUMN BEARING SUPPORT - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Reformatted Control Column Bearing Support inspection into Task 27-10-05-2200. Added Panel 143BBC to items B.(1) & D.(1)
27-10-11	FUSELAGE AILERON CABLE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-10-15	AILERON TRIM TAB - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Reformatted existing free play check into Task 27-10-15-7200. Added task 27-10-15-6400. Added Tasks: <ul style="list-style-type: none"> Aileron Trim Tab Actuator Lubrication (27-10-15-6400)
27-10-17	AILERON TRIM TAB CABLE (WHEEL WELL TO TRIM TAB CONTROL) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Added note to Paragraph 2.B. to reference Figure 401 for proper cable installation. Added procedure steps to check operation of aileron trim control system and proper trim tab movement.
27-10-19	AILERON TRIM TAB ACTUATOR AND OUTBOARD CABLE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-10-23	UNIVERSAL TRAVEL BOARD- ALTERNATE METHOD - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-20-05	RUDDER CABLE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-20-09	RUDDER PEDALS AND RUDDER PEDAL ARM - INSPECTION/CHECK	<ul style="list-style-type: none"> Changed document title to "Rudder Pedals and Rudder Pedal Arm" from "Rudder Pedal Arm." Revised section for inspection program update. Reformatted existing inspection information into task 27-20-09-2200. Added tasks 27-20-09-2100, 27-20-09-6400, and 27-20-09-6401.
27-20-11	RUDDER TRIM TAB - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Updated reference for Rudder Control System rigging procedure in Step B.5.
27-20-11	RUDDER TRIM TAB - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Reformatted the Rudder Trim Tab Inspection into Task 27-20-11-7200. Added task 27-20-11-6400.
27-20-13	FORWARD RUDDER TRIM TAB CABLE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-20-15	RUDDER TRIM TAB ACTUATOR AND AFT CABLE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

27-20-19	RUDDER TRIM TAB - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Reformatted Rudder Trim Tab inspection into task 27-20-19-7200.
27-21-01	RUDDER BOOST SYSTEM - TROUBLESHOOTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-21-01	RUDDER BOOST SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added task 27-21-01-2100.
27-21-03	RUDDER BOOST TRANSDUCER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-30-01	ELEVATOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-30-05	ELEVATOR CONTROL CABLE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-30-07	ELEVATOR TRIM TAB - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-30-07	ELEVATOR TRIM TAB - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Reformatted existing inspection into task 27-30-07-7200. Added Tasks 27-30-07-6400 and 27-30-07-7201.
27-30-09	FORWARD ELEVATOR TRIM TAB CABLE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-30-11	VERTICAL ELEVATOR TRIM TAB CABLE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-30-13	ELEVATOR TRIM TAB ACTUATOR AND CABLE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-30-21	ELEVATOR BOB-WEIGHT AND STOP - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Reformatted existing inspection into task 27-30-21-2200.
27-30-23	ELEVATOR BOB-WEIGHT LINK ASSEMBLY - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Reformatted existing inspection into task 27-30-23-2200.
27-30-25	UNIVERSAL TRAVEL BOARD-ALTERNATE METHOD - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-31-01	STALL WARNING - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 27-31-01-7100.
27-50-03	FLAP CONTROL - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-50-05	FLAP TRACK - SERVICING	<ul style="list-style-type: none"> Changed Item 02-013 in Table 301 to 02-017 and changed Recommended Materials to "Dry Powder Lubricant". Removed wear limit dimensions and illustration Figure 301 as this information is covered in section 27-50-05, 801.

27-50-05	FLAP TRACK - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-50-07	FLAP MOTOR AND GEARBOX - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-50-07	FLAP MOTOR AND GEARBOX - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-50-09	FLAP ACTUATOR - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-50-11	FLAP SAFETY MECHANISM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added task 27-50-11-7200.
27-50-13	FLAP FLEXIBLE DRIVE SHAFT - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> New section for removal/installation of the flap flexible drive shafts.
27-50-13	FLAP FLEXIBLE DRIVE SHAFT - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added task 27-50-13-2200.
27-50-13	FLAP FLEXIBLE DRIVE SHAFT - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
27-70-01	CONTROL LOCK - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update.. Added tasks 27-70-01-2100.
Chapter 28	LIST OF EFFECTIVE PAGES	
Chapter 28	TABLE OF CONTENTS	
28-10-01	FUEL CELL - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-20-00	FUEL DISTRIBUTION - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added General Visual Inspection tasks 28-20-00-2100, 28-20-00-2101, 28-20-00-2102, 28-20-00-2103, 28-20-00-2104, 28-20-00-2105, 28-20-00-2106, and 28-20-00-2107. Added Detailed Inspection tasks 28-20-00-2200, 28-20-00-2201, and 28-20-00-2202. Added Operation Check tasks 28-20-00-7100, 28-20-00-7101, and 28-20-00-7102. Added Special Detail Inspection task 28-20-00-2800.
28-20-00	FUEL DISTRIBUTION - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-20-01	ENGINE-DRIVEN FUEL BOOST PUMP - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-20-03	STANDBY BOOST PUMP - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-20-07	FIREWALL SHUTOFF VALVE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Added Firewall Shutoff Valve permitted leak rate to this section from Chapter 5-11-00.

28-20-07	FIREWALL SHUTOFF VALVE - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task 28-20-07-7100 and task format to existing inspection procedure.
28-20-09	CROSSFEED VALVE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-21-00	FUEL DISTRIBUTION - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-21-00	FUEL DISTRIBUTION - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added tasks 28-21-00-2200 and 28-21-00-7200.
28-21-01	EXTENDED RANGE FUEL TANK - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-21-03	EXTENDED RANGE FUEL TANK FUEL STRAINER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-21-07	EXTENDED RANGE FUEL TANK CHECK VALVE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-21-11	EXTENDED RANGE FUEL TANK FLOAT SWITCH - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-21-15	EXTENDED RANGE FUEL TANK MOTIVE FLOW VALVE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-21-17	AUXILIARY FUEL TANK TRANSFER RETURN VALVE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-40-00	FUEL QUANTITY INDICATING SYSTEM - TROUBLESHOOTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-40-00	FUEL QUANTITY INDICATING SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added task 28-40-00-7100.
28-40-01	NACELLE FUEL QUANTITY PROBE - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-40-03	INBOARD FUEL QUANTITY PROBES (LEADING EDGE AND AFT FUEL CELLS) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
28-40-05	OUTBOARD FUEL QUANTITY PROBES (INTEGRAL WET WING FUEL CELL) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 30	LIST OF EFFECTIVE PAGES	
Chapter 30	TABLE OF CONTENTS	
30-10-00	SURFACE DEICER SYSTEM - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
30-10-00	SURFACE DEICER SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added tasks 30-10-00-2100 and 30-10-00-7100

30-10-01	SURFACE DEICER BOOT - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
30-10-01	SURFACE DEICER BOOT - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added tasks 30-10-01-2100, 30-10-01-7100, and 30-10-01-7200.
30-10-01	SURFACE DEICER BOOT - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
30-10-03	TEST CONTROL STRIPS (GOODRICH OR SMR CONVENTIONAL DEICER BOOTS) - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
30-20-01	ENGINE INERTIAL ANTHCING SYSTEM - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
30-20-01	ENGINE INERTIAL ANTHCING SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added tasks 30-20-01-2200 and 30-20-01-7100.
30-20-03	ANTHCE LIP - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
30-40-05	WINDSHIELD WIPER - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
30-40-11	WINDOW DEFOG AIR FILTER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
30-40-13	WINDOW DEFOG SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added tasks 30-40-13-2100 and 30-40-13-9600.
30-60-00	PROPELLER ELECTRIC DEICER SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
30-60-01	PROPELLER DEICER BOOT - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
30-60-01	PROPELLER DEICER BOOT - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 30-60-01-2200 and task format to existing inspection procedure. Added tasks 30-60-01-2100 and 30-60-01-7100.
30-60-05	SLIP RING - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 31	LIST OF EFFECTIVE PAGES	
Chapter 31	TABLE OF CONTENTS	
31-10-00	INSTRUMENT AND CONTROL PANELS - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program tasks. Added tasks 31-10-00-2100, 31-10-00-2101, 31-10-00-2102, and 31-10-00-7100.
31-10-17	FUEL CONTROL PANEL FUEL QUANTITY GAGE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Added steps to disconnect and reconnect illumination wiring to the back of the fuel gage.

31-11-01	LEFT FORWARD FLIGHT COMPARTMENT EQUIPMENT PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
31-11-03	RIGHT FORWARD FLIGHT COMPARTMENT EQUIPMENT PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
31-30-01	PRINTED CIRCUIT CARD RACK - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
31-30-03	PRINTED CIRCUIT CARD BOX - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
31-40-11	MAINTENANCE DIAGNOSTIC COMPUTER (MDC-3110) - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
31-61-01	FILE SERVER UNIT (FSU-5010) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
31-61-03	FSU EXTERNAL COMPENSATION UNIT (ECU-3000) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
31-63-03	NO. 3 VHF TRANSCEIVER (VHF-4000) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
31-63-05	COMMUNICATIONS MANAGEMENT UNIT (CMU-4000) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
31-63-07	EXTERNAL COMPENSATION UNIT (ECU-3000) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 32	LIST OF EFFECTIVE PAGES	
Chapter 32	TABLE OF CONTENTS	
32-10-01	MAIN LANDING GEAR SHOCK ABSORBER - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-10-03	MAIN LANDING GEAR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-10-03	MAIN LANDING GEAR - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added General Visual Inspection tasks 32-10-03-2100, 32-10-03-2101, 32-10-03-2102, 32-10-03-2103, and 32-10-03-2104. Added Detail Inspection tasks 32-10-03-2200, 32-10-03-2201, 32-10-03-2202, 32-10-03-2203, 32-10-03-2204, 32-10-03-2205, 32-10-03-2206, 32-10-03-2207, 32-10-03-2208, 32-10-03-2209, 32-10-03-2210, and 32-10-03-2211. Added Lubrication inspection tasks 32-10-03-6400, 32-10-03-6401, 32-10-03-6402, and 32-10-03-6403. Added Operational Check task 32-10-03-7100. Added Restoration task 32-10-03-9600.
32-10-05	MAIN LANDING GEAR DOOR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

32-10-07	MAIN LANDING GEAR TORQUE KNEE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-11-01	MAIN LANDING GEAR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Updated Grease in Table 401.
32-11-03	MAIN LANDING GEAR DOOR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-20-01	NOSE LANDING GEAR STRUT - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-20-03	NOSE LANDING GEAR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-20-03	NOSE LANDING GEAR - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added General Visual Inspection tasks 32-20-03-2100, 32-20-03-2101, 32-20-03-2102, 32-20-03-2103, 32-20-03-2104, and 32-20-03-2105. Added Detailed Inspection tasks 32-20-03-2200, 32-20-03-2201, 32-20-03-2202, 32-20-03-2203, 32-20-03-2204, 32-20-03-2205, 32-20-03-2206, 32-20-03-2207, 32-20-03-2208, 32-20-03-2209, 32-20-03-2210, and 32-20-03-2211. Added Restoration task 32-20-03-9600.
32-20-05	NOSE LANDING GEAR DOOR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-20-09	NOSE LANDING GEAR DRAG BRACE - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 32-20-09-2100 and task format to existing inspection procedure.
32-20-11	SHIMMY DAMPER - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-20-11	SHIMMY DAMPER - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for the inspection program update. Added task 32-20-11-2100.
32-30-00	EXTENSION AND RETRACTION - TROUBLESHOOTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made. Deleted duplicate "Troubleshooting" in document title.
32-30-00	EXTENSION AND RETRACTION - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bars. No technical data changes were made. Deleted duplicate 'Maintenance Practices' from section title.
32-30-00	EXTENSION AND RETRACTION - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added task 32-30-00-2100, 32-30-00-2101, 32-30-00-2102, 32-30-00-7100, 32-30-00-7101, 32-30-00-7102, 32-30-00-7200, 32-30-00-7201, and 32-30-00-7202.
32-30-01	HYDRAULIC SYSTEM - SERVICING	<ul style="list-style-type: none"> Corrected Chapter 5-11-00 references in accordance with inspection program update.
32-30-01	HYDRAULIC SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added tasks 32-30-01-2100, 32-30-01-2101, 32-30-01-9600, and 32-30-01-9601.

32-30-01	HYDRAULIC SYSTEM - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-03	LANDING GEAR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bars. No technical data changes were made.
32-30-03	LANDING GEAR - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added task 32-30-03-2200.
32-30-05	MAIN LANDING GEAR ACTUATOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-05	MAIN LANDING GEAR ACTUATOR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bars. No technical data changes were made.
32-30-05	MAIN LANDING GEAR ACTUATOR - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 32-30-05-2200 and task format to existing procedure. Added task 32-30-05-2100.
32-30-09	MAIN LANDING GEAR ACTUATOR BEARING SUPPORT - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-11	NOSE LANDING GEAR ACTUATOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-11	NOSE LANDING GEAR ACTUATOR - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 32-30-11-2200 and task format to existing procedure. Added procedure steps to remove and install nose gear actuator clevis attaching hardware and added illustration Figure 602 (In Task 32-30-11-2200) Added task 32-30-11-2100.
32-30-13	POWER PACK - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-13	POWER PACK - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-13	POWER PACK - CLEANING/PAINTING	<ul style="list-style-type: none"> Revised links to Chapter 5-11-00 section in accordance with inspection program update.
32-30-15	POWER PACK MOTOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-15	POWER PACK MOTOR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-17	SPERRY-VICKERS SELECTOR VALVE ASSEMBLY - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-19	GEAR-UP PRESSURE SWITCH - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

32-30-21	FLUID LEVEL SENSOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-27	SERVICE VALVE - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-27	SERVICE VALVE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-29	EMERGENCY EXTENSION HAND PUMP - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-29	EMERGENCY EXTENSION HAND PUMP - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-31	EMERGENCY EXTENSION HAND PUMP SUCTION LINE FILTER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-30-33	LANDING GEAR FILL RESERVOIR SCREEN - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made..
32-31-01	MAIN LANDING GEAR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-40-01	BRAKE SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added task 32-40-01-1600, 32-40-01-2100, 32-40-01-9600, and 32-40-01-9601.
32-40-01	BRAKE SYSTEM - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-40-07	NOSE LANDING GEAR WHEEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-40-11	MAIN LANDING GEAR WHEEL AND BRAKE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Updated main gear wheel torque values.
32-40-13	TIRES - SERVICING	<ul style="list-style-type: none"> Added ER airplane main landing gear tire pressures.
32-41-01	MAIN LANDING GEAR WHEEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Added warning to deflate tire before removing the axle nut. Updated main gear wheel torque values and installation procedures.
32-41-03	MAIN LANDING GEAR BRAKES - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-41-05	BRAKE SYSTEM - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-43-00	BRAKE DEICE SYSTEM - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-43-00	BRAKE DEICE SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section or inspection program update. Added tasks 32-43-00-2100 and 32-43-00-7100.
32-43-01	DISTRIBUTOR MANIFOLD - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

32-50-01	STEERING MECHANISM - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-50-03	STEERING LINK END PLAY - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-60-01	NOSE LANDING GEAR DRAG BRACE DOWNLOCK SWITCH AND ACTUATOR SWITCH - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-60-03	NOSE AND MAIN LANDING GEAR UP-POSITION SWITCH - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
32-60-05	MAIN LANDING GEAR DOWNLOCK SWITCH - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 33	LIST OF EFFECTIVE PAGES	
Chapter 33	TABLE OF CONTENTS	
33-10-01	EDGELIGHTED/ELECTROLUMINESCENT PANEL - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 33-10-01-2200 and task format to existing procedure.
33-10-05	PRINTED CIRCUIT BOARD - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
33-10-09	ENGINE FIRE F/W VALVE SWITCH LAMP - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
33-10-11	ENGINE FIRE EXTINGUISHER SWITCH LAMP - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bars. No technical data changes were made.
33-20-00	PASSENGER COMPARTMENT - DESCRIPTION AND OPERATION	<ul style="list-style-type: none"> Revised section to correct Chapter 5-11-00, 001 reference in accordance with the inspection program update.
33-20-01	LAMP REPLACEMENT - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
33-20-03	ASSEMBLY AND POTTING OF HIGH VOLTAGE CONNECTORS - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
33-20-05	COLD CATHODE POWER SUPPLY - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
33-40-00	EXTERIOR LIGHTING - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for the inspection program update. Added tasks 33-40-00-2100, 33-40-00-2101, 33-40-00-2102, 33-40-00-2103, 33-40-00-6100, 33-40-00-7100, 33-40-00-7101, and 33-40-00-7102.
33-40-01	WING TIP LIGHT ASSEMBLY - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
33-40-07	LAMP REPLACEMENT - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
33-50-00	EMERGENCY LIGHTING - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

33-50-00	EMERGENCY LIGHTING - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for the inspection program update. Added tasks 33-50-00-2100 and 33-50-00-9600.
Chapter 34	LIST OF EFFECTIVE PAGES	
Chapter 34	TABLE OF CONTENTS	
34-10-01	PITOT SYSTEM - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-10-01	PITOT SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added tasks 34-10-01-6100 and 34-10-01-7100.
34-10-03	PITOT MAST ASSEMBLY - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-10-05	STATIC SYSTEM - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-10-05	STATIC SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 34-10-05-7200 to existing inspection procedure.
34-11-00	AIR DATA SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added task 34-11-00-2200.
34-11-01	AIR DATA SYSTEM (RVSM COMPLIANT AIRPLANES) - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section section for inspection program update. Added task number 34-11-01-2200 and task format to existing inspection procedures.
34-11-03	RVSM CRITICAL REGION CORNER MARKINGS - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-13-03	AIR DATA SYSTEM (RVSM COMPLIANT AIRPLANES) - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for the inspection program update. Added task number 34-13-03-2200 and task format to existing inspection procedures.
34-13-05	RVSM CRITICAL REGION CORNER MARKINGS - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-20-03	AVIONICS COOLING BLOWER - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added task 34-20-03-7100.
34-21-07	ATTITUDE HEADING SYSTEM (AHS) - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-21-09	ATTITUDE HEADING SYSTEM (AHS) COMPASS - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-23-05	ELECTRONIC STANDBY INSTRUMENT SYSTEM (ESIS) BATTERY (PS835D) - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added tasks 34-23-05-7200, 34-23-05-7201, and 34-23-05-7202.
34-23-07	ELECTRONIC STANDBY INSTRUMENT SYSTEM ESIS COMPASS - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-30-01	GLIDESLOPE ANTENNA - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

34-40-03	RADAR ANTENNA - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-41-01	WEATHER RADAR RECEIVER/TRANSMITTER/ANTENNA (RTA-852) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-41-01	WEATHER RADAR RECEIVER/TRANSMITTER/ANTENNA (RTA-852) - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-46-05	TCAS ANTENNA (TRE-920) - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-49-01	TERRAIN AWARENESS AND WARNING SYSTEM (TAWS+) COMPUTER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-57-00	DATA BASE UNIT (DBU-4100) - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
34-59-00	DATA BASE UNIT (DBU-5000) - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 35	LIST OF EFFECTIVE PAGES	
Chapter 35	TABLE OF CONTENTS	
35-00-00	OXYGEN - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
35-00-00	OXYGEN - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
35-00-00	OXYGEN - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added tasks 35-00-00-2100, 35-00-00-7200, 35-00-00-7201, 35-00-00-7202.
35-10-01	CREW OXYGEN MASK - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 35-10-01-2200 and task format to existing inspection procedure. Added task 35-10-01-9600.
35-10-01	CREW OXYGEN MASK - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
35-20-03	PASSENGER OXYGEN SHUTOFF VALVE PACKING - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Revised Chapter 5-11-00 reference in accordance with inspection program update.
35-20-05	PASSENGER OXYGEN MASK - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 35-20-05-7101 and task format to existing passenger oxygen mask inspection. Added Tasks 35-20-05-2200, 35-20-05-7100, and 35-20-05-9600.

35-20-05	PASSENGER OXYGEN MASK - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
35-20-07	BAROMETRIC PRESSURE SWITCH - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected Chapter 5 reference in accordance with the inspection program update.
Chapter 36	LIST OF EFFECTIVE PAGES	
Chapter 36	TABLE OF CONTENTS	
36-10-01	PRESSURE REGULATOR VALVE - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added tasks 36-10-01-7100 and 36-10-01-7101.
Chapter 37	LIST OF EFFECTIVE PAGES	
Chapter 37	TABLE OF CONTENTS	
37-00-00	VACUUM SYSTEM - GENERAL	<ul style="list-style-type: none"> Revised Chapter 5 references in accordance with the inspection program update.
37-10-01	VACUUM REGULATOR VALVE - CLEANING/PAINTING	<ul style="list-style-type: none"> Revised section for the inspection program update. Added task number 37-10-01-1600 and task format to existing procedure.
37-10-03	INSTRUMENT AIR FILTER - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 37-10-03-9600.
Chapter 38	LIST OF EFFECTIVE PAGES	
Chapter 38	TABLE OF CONTENTS	
38-30-00	WASTE DISPOSAL - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added tasks 38-30-00-2100 and 38-30-00-2101.
38-30-01	TOILET - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added task 38-30-01-2100.
38-35-01	FORWARD FACING CHEMICAL TOILET/MONOGRAM - SERVICING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
38-37-01	VANITY UNIT/OVERBOARD WATER DRAIN TUBE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 51	LIST OF EFFECTIVE PAGES	
Chapter 51	TABLE OF CONTENTS	
51-00-00	STRUCTURES - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
51-00-00	STRUCTURES - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 51-00-00-2800 and task format to existing inspection procedure.
51-70-03	SECONDARY STRUCTURE - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 52	LIST OF EFFECTIVE PAGES	
Chapter 52	TABLE OF CONTENTS	

52-10-01	CABIN ENTRANCE DOOR - SERVICING	01 <ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
52-10-01	CABIN ENTRANCE DOOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
52-10-01	CABIN ENTRANCE DOOR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
52-10-01	CABIN ENTRANCE DOOR - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 52-10-01-7100 and task format to existing procedure. Added Tasks 52-10-01-2100, 52-10-01-2200, and 52-10-01-6400.
52-10-03	NEW CABIN ENTRANCE DOOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
52-10-09	FOLDING STEP - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
52-10-13	CABIN ENTRANCE DOOR SEAL - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
52-20-01	EMERGENCY EXIT DOOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
52-20-01	EMERGENCY EXIT DOOR - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 52-20-01-2200 and task format to existing procedure. Added task 52-20-01-6400.
52-30-00	CARGO DOOR AND AIRSTAIR DOOR - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 52-30-00-2100, 52-30-00-2200, 52-30-00-6400, and 52-30-00-7100.
52-30-01	CARGO DOOR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
52-30-09	AIRSTAIR DOOR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made..
52-30-11	NEW AIRSTAIR DOOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
52-30-13	FOLDING STEP - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
52-30-15	AIRSTAIR DOOR DAMPER - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
52-40-00	ACCESS DOORS - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added tasks 52-40-00-2100, 52-40-00-2101, 52-40-00-2102, 52-40-00-2103, 52-40-00-2104, and 52-40-00-2105.
Chapter 53	LIST OF EFFECTIVE PAGES	

Chapter 53	TABLE OF CONTENTS	
53-00-00	FUSELAGE - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added tasks 53-00-00-2100, 53-00-00-2101, 53-00-00-2102, 53-00-00-2103, 53-00-00-2104, 53-00-00-2105, 53-00-00-2106, 53-00-00-2107, 53-00-00-2108, 53-00-00-2109, 53-00-00-2110, 53-00-00-2111, 53-00-00-2112, 53-00-00-2113, 53-00-00-2114, 53-00-00-2115, and 53-00-00-2116.
53-10-00	MAIN FRAME - INSPECTION/CHECK	<ul style="list-style-type: none"> Added this section for inspection program update.. Added tasks 53-10-00-2100, 53-10-00-2101, 53-10-00-2102, 53-10-00-2103, 53-10-00-2104, 53-10-00-2105, 53-10-00-2106, 53-10-00-2107, 53-10-00-2108, 53-10-00-2109, 53-10-00-2110, 53-10-00-2111, 53-10-00-2112, and 53-10-00-2113.
53-10-01	AFT FUSELAGE MOISTURE DRAINAGE SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 53-10-01-2100 and task format to existing inspection procedure.
53-11-03	MAIN LANDING GEAR, NOSE WHEEL WELL SOUND DEADENING COATING - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
53-13-05	TUNED VIBRATION ABSORBER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
53-13-07	SKIN DAMPING PANEL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made..
53-13-09	MAIN LANDING GEAR, NOSE WHEEL WELL SOUND DEADENING COATING - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
53-30-00	SEAT TRACKS - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
53-30-01	COCKPIT SEAT ATTACH FITTINGS - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 55	LIST OF EFFECTIVE PAGES	
Chapter 55	TABLE OF CONTENTS	
55-10-01	HORIZONTAL STABILIZER - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for new inspection program update. Added Task 55-10-01-2800.
55-20-01	ELEVATOR BALANCING - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
55-30-01	VERTICAL STABILIZER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
55-30-01	VERTICAL STABILIZER - INSPECTION/CHECK	<ul style="list-style-type: none"> Added this section for inspection program update. Added tasks 55-30-01-2100 and 55-30-01-2800.

55-40-01	RUDDER BALANCING - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
55-40-03	RUDDER TRIM MOISTURE DRAIN - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 55-40-03-2200 and task format to existing procedure.
Chapter 56	LIST OF EFFECTIVE PAGES	
Chapter 56	TABLE OF CONTENTS	
56-00-00	WINDOWS - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task numbers 56-00-00-2100 and 56-00-00-2101 and task format to existing procedures. Added task 56-00-00-2200.
56-00-00	WINDOWS - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-00-00	WINDOWS - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-10-01	WINDSHIELD - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 56-10-01-2100 and task format to existing inspection procedure. Added Tasks 56-10-01-2101 and 56-10-01-2200.
56-10-01	WINDSHIELD - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-10-03	SIDE WINDOW - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-10-11	WINDSHIELD ANTISTATIC TAB - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-10-11	WINDSHIELD ANTISTATIC TAB - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-10-11	WINDSHIELD ANTISTATIC TAB - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-20-01	CABIN OUTER WINDOW - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-20-03	POLARIZED WINDOW - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-20-05	EMERGENCY EXIT POLARIZED WINDOW - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-20-07	VESTIBULE WINDOW - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Deleted duplicate aircraft serialization text from section title. No technical data changes were made.
56-20-09	BAGGAGE COMPARTMENT WINDOW - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

56-21-01	CABIN OUTER WINDOW - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-21-03	ELECTROCHROMIC WINDOW SHADE - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-21-09	VESTIBULE WINDOW - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bars. No technical data changes were made.
56-21-11	BAGGAGE COMPARTMENT WINDOW - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bars. No technical data changes were made.
56-23-01	CABIN OUTER WINDOW - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-23-03	VESTIBULE WINDOW - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
56-23-05	BAGGAGE COMPARTMENT WINDOW - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 57	LIST OF EFFECTIVE PAGES	
Chapter 57	TABLE OF CONTENTS	
57-00-00	WINGS - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added inspection tasks 57-00-00-2100, 57-00-00-2101, 57-00-00-2102, 57-00-00-2103, 57-00-00-2104, 57-00-00-2105, 57-00-00-2106, 57-00-00-2200, 57-00-00-2300, 57-00-00-2500, 57-00-00-2501, 57-00-00-2800, 57-00-00-2801, 57-00-00-6100, and 57-00-00-6400 to this section.
57-10-01	CENTER WING - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added inspection tasks 57-10-01-2500, 57-10-01-2501, 57-10-01-2502, and 57-10-01-2503.
57-20-01	OUTER WING - MAINTENANCE PRACTICES	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
57-20-01	OUTER WING - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
57-20-01	OUTER WING - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added tasks 57-20-01-2100, 57-20-01-2500, 57-20-01-2501, and 57-20-01-2502.
57-60-01	AILERON BALANCING - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 61	LIST OF EFFECTIVE PAGES	
Chapter 61	TABLE OF CONTENTS	
61-10-01	PROPELLER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Added Lubricating Oil in Table 401 and informational Notes.
61-10-01	PROPELLER - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

61-10-01	PROPELLER - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 61-10-01-2100 and task format to existing inspection procedure. Added note to 2.D(2). Added Tasks 61-10-01-2101, 61-10-01-2102, 61-10-01-2103, 61-10-01-2104, 61-10-01-2105, 61-10-01-2200, 61-10-01-6400, 61-10-01-9600, 61-10-01-9601, and 61-10-01-9602.
61-10-01	PROPELLER - CLEANING/PAINTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
61-10-03	PROPELLER SHAFT OIL SEAL - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
61-20-05	OVERSPEED GOVERNOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
61-20-05	OVERSPEED GOVERNOR - INSPECTION/CHECK	<ul style="list-style-type: none"> Updated the propeller RPM values to match those found in the Pilot's Operating Handbook.
61-21-00	AUTOFEATHERING SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 61-21-00-7100 and task format to existing procedure. Added task 61-21-00-2100.
61-21-01	AUTOFEATHER PRESSURE SWITCH - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
61-21-03	AUTOFEATHER POWER LEVER SWITCH - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
61-23-00	SYNCHROPHASING - TROUBLESHOOTING	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
61-23-00	SYNCHROPHASING - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
61-23-00	SYNCHROPHASING - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 61-23-00-7100 and task format to existing procedure.
Chapter 71	LIST OF EFFECTIVE PAGES	
Chapter 71	TABLE OF CONTENTS	
71-00-01	ENGINE - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 71-00-01-2100, 71-00-01-2101, 71-00-01-2102, 71-00-01-2103, 71-00-01-2200, 71-00-01-2201, 71-00-01-2202, 71-00-01-9600, 71-00-01-9601, 71-00-01-9602, and 71-00-01-9603.
71-10-00	COWLING - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 71-10-00-2100.

71-10-01	UPPER FORWARD COWLING - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Added note to make sure hook-cam is engaged during installation. Added caution to reset hook cam before installation.
71-10-09	UPPER AFT COWLING DOOR - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
71-20-01	ENGINE MOUNT - APPROVED REPAIRS	<ul style="list-style-type: none"> Added Engine Mount Truss repair instructions.
71-20-03	ENGINE MOUNT VIBRATION ISOLATOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Updated illustration, removed washers from isolator mount.
71-70-00	FUEL PURGE SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 71-70-00-1600 and 71-70-00-7200.
71-70-01	FUEL PURGE TANK - CLEANING/PAINTING	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 71-70-01-1600 and task format to existing procedure.
71-70-03	FUEL PURGE SYSTEM AIR FILTER - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 71-70-03-1600 and task format to existing procedure.
71-70-05	FUEL PURGE SYSTEM CHECK VALVE - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 74	LIST OF EFFECTIVE PAGES	
Chapter 74	TABLE OF CONTENTS	
74-00-00	IGNITION - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 74-00-00-2100.
74-10-03	AUTO-IGNITION PRESSURE SWITCH - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
74-10-03	AUTO-IGNITION PRESSURE SWITCH - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added Task number 74-10-03-7100. and task format to existing procedure.
74-10-05	IGNITION EXCITER CONTROL BOX - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 76	LIST OF EFFECTIVE PAGES	
Chapter 76	TABLE OF CONTENTS	
76-00-00	ENGINE CONTROLS - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 76-00-00-2100, 76-00-00-2101, 76-00-00-6400, and 76-00-00-7100.
76-10-09	CONDITION CONTROL CATCH GATE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
76-10-09	CONDITION CONTROL CATCH GATE - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added Task number 76-10-09-2100 and task format to existing procedure. Added task 76-10-09-2200.

76-10-15	GROUND RUN - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 76-10-15-7100 and task format to existing inspection.
76-10-19	POWER LEVER DETENT PIN - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 76-10-19-2200 and task format to existing procedure.
76-10-21	ENGINE CONTROL CABLE - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Updated O-ring part numbers.
76-10-21	ENGINE CONTROL CABLE - APPROVED REPAIRS	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
Chapter 77	LIST OF EFFECTIVE PAGES	
Chapter 77	TABLE OF CONTENTS	
77-00-00	ENGINE INDICATING - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 77-00-00-7100.
77-10-01	ENGINE GROUND PERFORMANCE - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
77-10-03	N1 AND N2 INDICATOR SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
77-10-09	TORQUE INDICATION AND CALIBRATION - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Updated number for P1 and P2 in Figure 501.
77-10-11	TORQUE TRANSMITTER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
77-20-03	ITT INDICATING SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
77-20-05	ITT INDICATING SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
77-30-01	FUEL FLOW SYSTEM - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
77-40-05	ENGINE INDICATION REVERSION - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 77-40-05-7200 and task format to existing procedure.
77-40-07	FUEL FLOW INDICATION - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
77-40-09	PROPELLER RPM INDICATION - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
77-40-13	AUTOFEATHER INDICATOR - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
77-40-15	N1 INDICATION - INSPECTION/CHECK	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.

77-40-17	OIL TEMPERATURE INDICATION - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 77-40-17-7100 and task format to existing procedure.
77-40-19	OIL PRESSURE INDICATION - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 77-40-19-7100 and task format to existing procedure.
Chapter 78	LIST OF EFFECTIVE PAGES	
Chapter 78	TABLE OF CONTENTS	
78-00-00	EXHAUST - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Task 78-00-00-2100.
Chapter 79	LIST OF EFFECTIVE PAGES	
Chapter 79	TABLE OF CONTENTS	
79-00-00	OIL - SERVICING	<ul style="list-style-type: none"> Revised Chapter 5-11-00 reference in accordance with inspection program updates.
79-00-00	OIL - INSPECTION/CHECK	<ul style="list-style-type: none"> Added section for inspection program update. Added Tasks 79-00-00-2100, 79-00-00-2101, 79-00-00-6100 and 79-00-00-9600.
79-10-01	OIL COOLER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Moved requirement to replace the oiler cooler when contaminated or plugged to this section from Chapter 5-11-00, 001.
79-10-07	OIL TANK DRAIN SHUTOFF VALVE - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made..
79-30-01	OIL TEMPERATURE BULB - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
79-30-01	OIL TEMPERATURE BULB - ADJUSTMENT/TEST	<ul style="list-style-type: none"> Removed resistance values shown in Step 2.A.(5) and added illustration Figure 502 with resistance values specified in MIL-DTL-7990C.
79-30-03	OIL PRESSURE TRANSDUCER - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
79-30-05	CHIP DETECTOR - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.
79-30-05	CHIP DETECTOR - INSPECTION/CHECK	<ul style="list-style-type: none"> Revised section for inspection program update. Added task number 79-30-05-2200 and task format to existing procedure.
79-30-07	LOW OIL PRESSURE SWITCH - REMOVAL/INSTALLATION	<ul style="list-style-type: none"> Corrected missing revision bar. No technical data changes were made.