

## 1. PLANNING INFORMATION

### 1.A. EFFECTIVITY

#### 1.A.1. Helicopters/installed equipment or parts

AS350 helicopter versions B, BA, BB, B1, B2, B3, D and L1 that have an equipped main rotor shaft, P/N 350A37-1290-XX, with a serial number (S/N):

- M2402 to M6500, except for S/N M6476 - M6479,

or

- strictly lower than S/N FR3146 except for S/N FR2495 - FR2681 - FR2740 - FR2791 - FR2799 - FR2801 - FR2829 - FR2854 - FR2921 - FR2927 - FR2928 - FR2929 - FR2948 - FR2956 - FR2964 - FR2967 - FR3021 - FR3029 - FR3031 - FR3032 - FR3035 - FR3044 - FR3048 - FR3056 - FR3057 - FR3059 - FR3060 - FR3061 - FR3063 - FR3064 - FR3071 - FR3072 - FR3073 - FR3074 - FR3075 - FR3076 - FR3077 - FR3080 - FR3085 - FR3086 - FR3087 - FR3088 - FR3089 - FR3090 - FR3091 - FR3092 - FR3093 - FR3094 - FR3099 - FR3100 - FR3101 - FR3103 - FR3107 - FR3108 - FR3109 - FR3110 - FR3111 - FR3112 - FR3113 - FR3114 - FR3115 - FR3117 - FR3118 - FR3119 - FR3120 - FR3121 - FR3124 - FR3125 - FR3127 - FR3128 - FR3129 - FR3130 - FR3131 - FR3132 - FR3133 - FR3134 - FR3135 - FR3136 - FR3137 - FR3140 - FR3141 - FR3142 - FR3143 - FR3144 - FR3145.

#### **NOTE**

*Refer to the Log Card (FM) of the main rotor mast to identify the part number and the serial number of the rotor shaft*

#### 1.A.2. Non-installed equipment or parts

- Equipped main rotor shaft, P/N 350A37-1290-XX, with a S/N:

. M2402 to M6500 except for S/N M6476 - M6479,

or

. strictly lower than S/N FR3146 except for S/N FR2495 - FR2681 - FR2740 - FR2791 - FR2799 - FR2801 - FR2829 - FR2854 - FR2921 - FR2927 - FR2928 - FR2929 - FR2948 - FR2956 - FR2964 - FR2967 - FR3021 - FR3029 - FR3031 - FR3032 - FR3035 - FR3044 - FR3048 - FR3056 - FR3057 - FR3059 - FR3060 - FR3061 - FR3063 - FR3064 - FR3071 - FR3072 - FR3073 - FR3074 - FR3075 - FR3076 - FR3077 - FR3080 - FR3085 - FR3086 - FR3087 - FR3088 - FR3089 - FR3090 - FR3091 - FR3092 - FR3093 - FR3094 - FR3099 - FR3100 - FR3101 - FR3103 - FR3107 - FR3108 - FR3109 - FR3110 - FR3111 - FR3112 - FR3113 - FR3114 - FR3115 - FR3117 - FR3118 - FR3119 - FR3120 - FR3121 - FR3124 - FR3125 - FR3127 - FR3128 - FR3129 - FR3130 - FR3131 - FR3132 - FR3133 - FR3134 - FR3135 - FR3136 - FR3137 - FR3140 - FR3141 - FR3142 - FR3143 - FR3144 - FR3145.

- Main rotor mast which has an equipped main rotor shaft, P/N 350A37-1290-XX, with a S/N:

. M2402 to M6500 except for S/N M6476 - M6479,

or

. strictly lower than S/N FR3146 except for S/N FR2495 - FR2681 - FR2740 - FR2791 - FR2799 - FR2801 - FR2829 - FR2854 - FR2921 - FR2927 - FR2928 - FR2929 - FR2948 - FR2956 - FR2964 - FR2967 - FR3021 - FR3029 - FR3031 - FR3032 - FR3035 - FR3044 - FR3048 - FR3056 - FR3057 - FR3059 - FR3060 - FR3061 - FR3063 - FR3064 - FR3071 - FR3072 - FR3073 - FR3074 - FR3075 - FR3076 - FR3077 - FR3080 - FR3085 - FR3086 - FR3087 - FR3088 - FR3089 - FR3090 - FR3091 - FR3092 - FR3093 - FR3094 - FR3099 - FR3100 - FR3101 - FR3103 - FR3107 - FR3108 - FR3109 - FR3110 - FR3111 - FR3112 - FR3113 - FR3114 - FR3115 - FR3117 - FR3118 - FR3119 - FR3120 - FR3121 - FR3124 - FR3125 - FR3127 - FR3128 - FR3129 - FR3130 - FR3131 - FR3132 - FR3133 - FR3134 - FR3135 - FR3136 - FR3137 - FR3140 - FR3141 - FR3142 - FR3143 - FR3144 - FR3145.