

TO: Holders of RR300 Series Operations and Maintenance Manual, Publication CSP 21009.

Reason: Revised cleaning procedure.

Component: Compressor Front Bearing Housing

Remarks: Contact Rolls-Royce

ADVANCED COPY

## **COMPRESSOR FRONT BEARING HOUSING CLEANING**

## TASK 72-30-11-100-801

- 1. Clean the Compressor Front Bearing Housing
  - A. General

This task gives you the procedure to clean the compressor front bearing housing.

B. Materials

None

C. Consumable Materials

None

D. Expendable Parts

None

E. Special Tools and Equipment

None

- F. References
  - (1) TASK 70-11-17-100-801, Clean with the Solvent in a Spray Booth, SPM.
  - (2) TASK 70-11-19-100-801, Clean with the Solvent in a Tank, SPM.
- G. Procedure

SUBTASK 72-30-11-110-001

- (1) Clean the compressor front bearing housing.
  - (a) Use the solvent in a spray booth or in a tank to clean the compressor front bearing housing (REF. TASK 70-11-17-100-801 or TASK 70-11-19-100-801).

**EFFECTIVITY: ALL** 

CLEANING-801

72-30-11

Page 601

Jul 31/23