

BULLETIN EVOLUTION OUTILLAGE N° S99_013_21_TM6518G003

TOOL CHANGE BULLETIN

DATE D'EDITION /ISSUE DATE: 07 MAY 21

EDITION ORIGINALE / ORIGINAL ISSUE

DATE DE DISPONIBILITE DOC. ESTIMEE (ESTIMATED DATE OF TECH PUBS AVAILABILITY)
December - 2021

1 MOTEUR / ENGINE

ARRIEL 2

ARRIUS 2

MAKILA 2

1.1 MOTEUR / ENGINE VARIANTS

ARRIEL 2 B, B1, B1A, C, CPM C1, C2, C2CG, S1, S2

ARRIUS 2 B1, B2, G1, K1, K2

MAKILA 2 A, A1

1.2 CONFIGURATION

Toutes TU – All TU

2 OUTILLAGE / TOOL INFORMATION

2.1 IDENTIFICATION

Ancien P/N <i>Old P/N</i>	Nouveau P/N <i>New P/N</i>	Désignation <i>Designation</i>	Qté <i>Qty</i>	SP* PC*
install-polybox-full-2.1.0.1	Install-polybox-full-BC-2.51	Pilote USB pour POLYBOX -TM6518G003 USB Driver for POLYBOX - TM6518G003	1	

* *Suivi périodique / Periodic check*

2.2 DESCRIPTION DE L'EVOLUTION / CHANGE DESCRIPTION

Le pilote USB « Install-polybox-full-BC-2.51 » permet au boîtier de communication POLYBOX TM6518G003 de communiquer par la liaison USB avec un PC équipé d'un environnement Windows 10. Pour terminer l'installation il n'est désormais plus nécessaire de réaliser une configuration manuelle particulière.

Le précédent pilote USB « install-polybox-full-2.1 » permet toujours de communiquer par la liaison USB avec un PC équipé d'un environnement Windows XP ou Windows 7.

The USB driver « Install-polybox-full-BC-2.51 » allows USB communication between the POLYBOX TM6518G003 and a laptop equipped with Windows 10 environment. It is no longer required to perform a configuration manually to finish the driver installation

The previous USB driver « install-polybox-full-2.1 » still allows USB communication between the POLYBOX TM6518G003 and a laptop equipped with Windows XP or Windows 7 environment.

3 NIVEAU DE MAINTENANCE D'APPLICATION / *APPLICABILITY LEVEL*

Opérateurs Centre de Maintenance Centre de réparation
Operators Maintenance Center Repair Center

3.1 UTILISATION / *USE*

Le boîtier de communication, POLYBOX TM6518G003, pour EECU permet de réaliser toutes les opérations de maintenance sur Calculateur Numérique de Régulation.

Le pilote USB « Install-polybox-full-BC-2.51 » et son manuel d'utilisation sont téléchargeables depuis :

- EngineLife® Customer Portal site web : MES E-SERVICES/ PIECES ET OUTILLAGES/Outillage – Télécharger le driver USB pour Windows 10 – outil de maintenance POLYBOX.

The EECU communication box POLYBOX TM6518G003 allows to perform all maintenance operations on the Electronic Engine Control Unit.

The USB driver « Install-polybox-full-BC-2.51 » and its user manual are downloadable from:

- EngineLife® Customer Portal website (MY E-SERVICES/ SPARE PARTS AND TOOLING/Tooling – Download USB Driver for Windows 10– POLYBOX maintenance tool.

Opérateurs Nouveau Remplace Alternative
Operators New Substitution Alternative
 N/A.

Centre de Maintenance Nouveau Remplace Alternative
Maintenance Center New Substitution Alternative
 N/A

Centre de réparation Nouveau Remplace Alternative
Repair Center New Substitution Alternative
 N/A.

3.2 TÂCHE(S) ASSOCIÉE(S) / *ASSOCIATED TASK(S)*

ARRIEL 2: 73-21-00-280-801 – Installation boîtier POLYBOX et lancement logiciel interface – *Installation of POLYBOX unit and interface software starting.*

ARRIUS 2: 73-21-00-280-809 – Installer outillage Boîtier POLYBOX et lancer logiciel interface – *Install POLYBOX tool and initiate interface software.*

MAKILA 2: 73-22-04-280-801 – Installation matérielle avec POLYBOX et lancement de l'outil informatique – *Hardware installation with POLYBOX and its tool software launch*

Le manuel d'utilisation du pilote « Install-polybox-full-BC-2.51 » est téléchargeable depuis - *The USB driver « Install-polybox-full-BC-2.51 » user manual is downloadable from:*

- EngineLife® Customer Portal

3.3 APPLICATION / *APPLICATION*

Nouvelle fabrication
New manufacturing

Outillage modifiable par l'utilisateur
Tool to be modified by the user

ILLUSTRATION OUTILLAGE TOOL ILLUSTRATION



NOMENCLATURE OUTILLAGE
BILL OF MATERIAL