

AW Family Manuals - IETP Update


Installation procedure

NOTE: This IETP Update must be used in conjunction with AW189 and/or AW149 IETPs.

If you reinstall an IETP, you must reinstall also this IETP Update. A new IETP issue will replace and supersede this IETP Update for that IETP.

The update is applicable to IETP in both server/client and internet based modes.


Select the IETP to update and click on **Next** to go on:




Select your IETP installation type (the choice must be the same of your IETP installation type, to allow the correct installation of the update):

- **Server :** applicable on IETP installed as 'Server/Stand-alone' on Laptops or on PCs.
- **Client :** applicable on IETP installed as 'Client' on Intranet PCs. This choice will be available only if applicable.
- **Internet :** applicable on IETP installed as 'Internet' on Laptops or on PCs.



Click on **Next** to go on:



Click on **Next** to confirm the folder where the IETP is installed:



Click on **Install** to continue with the installation:



Click on **Finish** to complete IETP Update setup.

