

Table 4-4. Unit to Figure Number Index.

UNIT	TITLE	FIGURE NUMBER
IAPS INTEGRATED AVIONICS PROCESSOR SYSTEM		
ICC-3000	IAPS Card Cage	Figure 4-2
CSU-3100	Configuration Strapping Unit	Figure 4-2
IEC-3001	IAPS Environmental Controller	Figure 4-2
IOC-3100	I/O Concentrator	Figure 4-2
MDC-3110	Maintenance Diagnostic Computer	Figure 4-2
PWR-3000	Power Supply	Figure 4-2
EFIS ELECTRONIC FLIGHT INSTRUMENT SYSTEM		
AFD-3010	Adaptive Flight Display (PFD and MFD)	Figure 4-4
DCP-3000	Display Control Panel	Figure 4-4
EIS ENGINE INDICATION SYSTEM		
DCU-3001	Data Concentrator Unit	Figure 4-5
ADS AIR DATA SYSTEM		
ADC-3000	Air Data Computer	Figure 4-6
AHS ATTITUDE HEADING SYSTEM		
AHC-3000	Attitude Heading Computer	Figure 4-7
ECU-3000	External Compensation Unit	Figure 4-7
FDU-3000	Flux Detector Unit	Figure 4-7
FCS FLIGHT CONTROL SYSTEM		
FGC-3000	Flight Guidance Computer	Figure 4-8
FGP-3000	Flight Guidance Panel	Figure 4-8
SVO-3000	Primary Servo (aileron, elevator, and rudder)	Figure 4-8
SVO-85B	Primary Servo (B300 rudder)	Figure 4-8
FMS FLIGHT MANAGEMENT SYSTEM		
FMC-3000	Flight Management Computer	Figure 4-9
CDU-3000	Control Display Unit	Figure 4-9
DBU-4100	Data Base Unit	Figure 4-9
RSS RADIO SENSOR SYSTEM		
ALT-4000	Radio Altimeter	Figure 4-10
ANT-462A	ADF Antenna (Single)	Figure 4-10
DME-4000	DME Transceiver	Figure 4-10
GPS-4000A	Global Positioning System	Figure 4-10
NAV-4000, NAV-4500	VHF Navigation Receiver	Figure 4-10

*Table 4-4. Unit to Figure Number Index. - Continued*

<b>UNIT</b>	<b>TITLE</b>	<b>FIGURE NUMBER</b>
RTU-4200, RTU-4220	Radio Tune Unit	Figure 4-10
TDR-94, TDR-94D	Mode S Transponder	Figure 4-10
TTR-4000	TCAS II Transmitter Receiver	Figure 4-10
VHF-4000	VHF Communication Transceiver	Figure 4-10
<b>WXR WEATHER RADAR SYSTEM</b>		
RTA-852	Receiver/Transmitter/Antenna	Figure 4-11